


PEB-2274

PEB-2274

3.5" Embedded Motherboard Board



Version 1.2

## Revision History

|      |                          |
|------|--------------------------|
| R1.0 | Preliminary              |
| R1.1 | Modify the page numbers. |
| R1.2 | Modify the typo          |
|      |                          |
|      |                          |
|      |                          |

## Contents

|   |                                                          |    |
|---|----------------------------------------------------------|----|
| 1 | Introduction .....                                       | 7  |
| 2 | Specifications .....                                     | 8  |
|   | 2.1 Supported Operating Systems .....                    | 9  |
|   | 2.2 Mechanical Dimensions .....                          | 10 |
|   | 2.3 Power Consumption .....                              | 12 |
|   | 2.4 Environmental Specifications .....                   | 13 |
| 3 | Block Diagram .....                                      | 14 |
| 4 | Hardware Configuration .....                             | 15 |
|   | 4.1 Jumpers and Connectors .....                         | 15 |
|   | 4.2 Jumper Settings .....                                | 16 |
| 5 | System Resources .....                                   | 33 |
|   | 5.1 Intel® Elkhart Lake SoC .....                        | 33 |
|   | 5.2 Main Memory .....                                    | 33 |
|   | 5.3 Installing the Single Board Computer .....           | 33 |
|   | 5.3.1 Chipset Component Driver .....                     | 34 |
|   | 5.3.2 Intel® UHD Graphics .....                          | 34 |
|   | 5.3.3 Intel LAN I210IT Gigabit Ethernet Controller ..... | 34 |
| 6 | BIOS Setup Items .....                                   | 35 |
|   | 7.2 BIOS Setup .....                                     | 35 |
|   | 6.2.1 Main .....                                         | 37 |
|   | 6.2.2 Configuration .....                                | 39 |

6.2.3 H/W Monitor ..... 69

6.2.4 Security ..... 72

6.2.5 Boot..... 75

6.2.6 Save & Exit..... 77

7 Troubleshooting ..... 79

7.1 Hardware Quick Installation ..... 79

7.2 BIOS Setting ..... 81

7.3 FAQ..... 82

8 Portwell Software Service ..... 91

9 Industry Specifications ..... 92

## Preface

This user's guide provides information about the components, features, connectors and BIOS Setup menus available on the PEB-2274. This document should be referred to when designing 3.5" Embedded board application. The other reference documents that should be used include the following:

- ✧ Intel Elkhart Lake Design Guide
- ✧ Intel Elkhart Lake Specification

Please contact Portwell Sales Representative for above documents.

## Disclaimer

The information contained within this user's guide, including but not limited to any product specification, is subject to change without notice.

Portwell provides no warranty with regard to this user's guide or any other information contained herein and hereby expressly disclaims any implied warranties of merchantability or fitness for any particular purpose with regard to any of the foregoing. Portwell assumes no liability for any damages incurred directly or indirectly from any technical or typographical errors or omissions contained herein or for discrepancies between the product and the user's guide. In no event shall Portwell be liable for any incidental, consequential, special, or exemplary damages, whether based on tort, contract or otherwise, arising out of or in connection with this user's guide or any other information contained herein or the use thereof.

## Trademarks

Product names, logos, brands, and other trademarks featured or referred to within this User's guide or the Portwell website, are the property of their respective trademark holders. These trademark holders are not affiliated with Portwell, our products, or our website.

## Warranty

Portwell makes no representation, warranty or guaranty, express or implied regarding the products except its standard form of limited warranty ("Limited

Warranty”). Portwell may in its sole discretion modify its Limited Warranty at any time and from time to time.

Beginning on the date of shipment to its direct customer and continuing for the published warranty period, Portwell represents that the products are new and warrants that each product failing to function properly under normal use, due to a defect in materials or workmanship or due to non conformance to the agreed upon specifications, will be repaired or exchanged, at Portwell’s option and expense.

### Certification

Portwell is certified to DIN EN ISO 9001:2000 standard.



### Technical Support

Portwell technicians and engineers are committed to providing the best possible technical support for our customers so that our products can be easily used and implemented.

We request that you first visit our website at <http://www.portwell.com.tw/support/> for the latest documentation, utilities and drivers, which have been made available to assist you. If you still require assistance after visiting our website then contact our technical support department by email at [tsd@mail.portwell.com.tw](mailto:tsd@mail.portwell.com.tw) for further assistance. Thank you!

## 1 Introduction

Portwell Inc., a world-leading innovator in the Industrial PC (IPC) market and a member of the Intel® Embedded and Communications Alliance (Intel ECA), announced today the Portwell PEB-2274 utilizing the Intel® ECX form factor based on the Elkhart Lake Intel® Atom x6425E, includes integrated, enhanced graphics and memory controllers on 10nm process technology, delivering significant power reduction and performance improvements. The PEB-2274 can provide the low power consumption for low profile fanless applications such as POS, Print Imaging, ATM, Kiosk, Medical, Panel PC, Digital Security and Digital Signage.

## 2 Specifications

|                            |                                                                                                                                                                                                           |
|----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Main Processor</b>      | ◆ Intel® Elkhart lake SoC                                                                                                                                                                                 |
| <b>System BIOS</b>         | ◆ AMI UEFI BIOS                                                                                                                                                                                           |
| <b>Main Memory</b>         | ◆ Up to 32GB in 1 slot DDR4 SO-DIMM socket.                                                                                                                                                               |
| <b>Graphics</b>            | ◆ Controller: Intel® UHD Graphics<br>◆ LVDS: Supports resolution up to 1920x1200<br>◆ DP: Supports DP ++1.2 4096x2160 @60Hz<br>◆ HDMI: Supports HDMI 2.0 4K x 2K @ 60 Hz                                  |
| <b>Expansion Interface</b> | ◆ 1 x M.2 E key, type 2230 for WIFI/BT device<br>◆ 1 x M.2 M key, type 2280 (SATA mode & PCIe x2 mode)<br>◆ 1 x M.2 B key (USB 2.0)                                                                       |
| <b>SATA Interface</b>      | ◆ One SATA port(SATA Gen3.0 6Gb/s)                                                                                                                                                                        |
| <b>Input/Output</b>        | ◆ Serial Ports: 6 (2 x RS-232/422/485, 4 x RS 232)<br>◆ USB Port: 4x USB 3.2 Gen2 ports on rear I/O, 1x USB 2.0 Header support additional 2 x USB2.0 connectors<br>◆ Audio Interface: Mic-In and Line-Out |
| <b>Ethernet</b>            | ◆ Supports 2 x Intel® i210IT with 2 x RJ-45                                                                                                                                                               |
| <b>High Drive GPIO</b>     | ◆ One pin-header for GPIO(8bit in / out)                                                                                                                                                                  |



|                                                            |                                                                                                                                                                                                                                                                 |
|------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Mechanical<br/>and<br/>environmental specifications</b> | <ul style="list-style-type: none"> <li>◆ Operating temperature: -40 ~ 85° C</li> <li>◆ Storage temperature: -40 ~85°C</li> <li>◆ Humidity: 10 ~ 95% non-condensing</li> <li>◆ Power supply voltage: 9V-36V DC in</li> <li>◆ Board size: 146 x 105 mm</li> </ul> |
| <b>Safety</b>                                              | <ul style="list-style-type: none"> <li>◆ CE, FCC</li> </ul>                                                                                                                                                                                                     |


## 2.1 Supported Operating Systems

The PEB-2274 supports the following operating systems.

- ✧ Windows 10\* (64 bit), IoT Enterprise
- ✧ Ubuntu

## 2.2 Mechanical Dimensions





## 2.3 Power Consumption

| Test Configuration       |                                                          |
|--------------------------|----------------------------------------------------------|
| CPU Type                 | Intel Atom® x6425E @3.0GHz                               |
| SBC BIOS                 | 1.00.00                                                  |
| Memory                   | WARIS DDR4 2133 8GB x1 SO-DIMM                           |
| Chipset Driver           | Intel® Chipset Device Software ,Version:10.1.19222.8341  |
| ME Driver                | Intel® Management Engine Components,Version:2242.3.34.0  |
| VGA Card                 | Onboard Intel® UHD Graphics                              |
| VGA Driver               | Intel® UHD Graphics ,Version:31.0.101.2114               |
| LAN Card #1              | Onboard Intel® I210 Gigabit Network Controller           |
| LAN Driver #1            | Intel® I210 Gigabit Network Controller ,Version:14.0.2.0 |
| LAN Card #2              | Onboard Intel® I210 Gigabit Network Controller #2        |
| LAN Driver #2            | Intel® I210 Gigabit Network Controller ,Version:14.0.2.0 |
| Audio Card               | Onboard Realtek ®Audio                                   |
| Audio Driver             | Realtek ®Audio Driver,Version:6.0.9244.1                 |
| Power Supply             | FSP GROUP INC. FSP120-AHAN1                              |
| M.2 (E-Key) Wi-Fi Module | Intel® Wireless-AC 9260 (9260NGW)                        |
| M.2 (M-Key) SSD Card     | WARIS 32GB M.2 2242 SSD (TS46EMM)                        |
| Hard Drive               | KINGSTON 128GB                                           |

| Power consumption(12V) |             |                     |                     |
|------------------------|-------------|---------------------|---------------------|
| Item                   | Power ON    | Full Loading 10 Min | Full Loading 30 Min |
| DC IN 12V              | 1.73A       | 1.98A               | 2.12A               |
| Device +12V            | 0.16A       | 0.15A               | 0.17A               |
| Device +5V             | 0.30A       | 0.32A               | 0.36A               |
| USB3.0 Loading Test    | 4.80V/0.96A |                     |                     |


## 2.4 Environmental Specifications

Storage Temperature : -40~85°C

Operation Temperature : -40~85°C

Humidity: 10 ~ 95% non-condensing


### 3 Block Diagram



## 4 Hardware Configuration

### 4.1 Jumpers and Connectors

This chapter indicates jumpers, headers, and connector's locations. Users may find useful information related to hardware settings in this chapter.



## 4.2 Jumper Settings

For users to customize PEB-2274's features. In the following sections, **Short** means covering a jumper cap over jumper pins; **Open** or **N/C** (Not Connected) means removing a jumper cap from jumper pins. Users can refer to Figure 1 for the Jumper allocations.


### Jumper Table

The jumper settings are schematically depicted in this manual as follows:

#### Jumper Function List:

| Jumper | Function                                 |
|--------|------------------------------------------|
| 1      | Clear RTC RAM jumper                     |
| 2      | Display Panel VCC Power Selection jumper |
| 3      | COM +5V/+12V Selection jumper            |
| 4      | AT/ATX Mode Configuration jumper         |


## 1: Clear RTC RAM jumper




### To erase the RTC RAM:

1. Turn OFF the computer and unplug the power cord.
2. Short-circuit pin 1-2 with a metal object or jumper cap for about 5-10 seconds.
3. Plug the power cord and turn ON the computer.
4. Hold down the <Del> key during the boot process and enter BIOS setup to re-enter data.


## 2 : Display Panel VCC Power Selection jumper



## 3 : COM +5V/+12V Selection jumper



## 4 : AT/ATX Mode Configuration jumper



AT\_ATX\_SEL




Jumper Function List:

| Connectors | Function                           |
|------------|------------------------------------|
| 1          | M.2 (E-key) Wi-Fi slot             |
| 2          | M.2 (E-key) Wi-Fi slot             |
| 3          | M.2 (E-key) Wi-Fi slot             |
| 4          | LVDS connector                     |
| 5          | M.2 (M-key) slot                   |
| 6          | Backlight Inverter Power connector |
| 7          | Serial Port connector              |
| 8          | Chassis intrusion connector        |
| 9          | DIMM slot                          |
| 10         | COM Debug connector                |
| 11         | Fan connector                      |
| 12         | Nano SIM Card slot                 |
| 13         | USB 2.0 connector                  |
| 14         | SATA Power connector               |
| 15         | DC-in Power connector              |
| 16         | SATA connector                     |
| 17         | I2C connector                      |
| 18         | SMBus connector                    |
| 19         | SPI TPM connector                  |

|    |                          |
|----|--------------------------|
| 20 | GPIO connector           |
| 21 | Power Button connector   |
| 22 | Stereo Out connector     |
| 23 | System Panel connector   |
| 24 | Line Out / Mic connector |


1 : M.2 (E-key) Wi-Fi slot




M.2(E-KEY)




2 : M.2 (B-key) slot




M.2\_B




### 3 : Battery connector



### 4 : LVDS connector




**5 : M.2 (M-key) slot**



M.2\_(SOCKET3)




**6: Backlight Inverter Power connector**




LCD\_BKLT\_PANEL




7 : Serial Port connector




8 : Chassis Intrusion connector




9 : COM Debug connector




10 : Fan Connector



## 11 : Nano SIM Card slot




## 12 : USB 2.0 connector




**WARNING: Do Not Connect a 1394 cable to the USB connectors. Doing so will damage the motherboard.**



13 : SATA 6Gb/s & SATA Power connector





14 : DC-in 4-Pin Power connector




## 15 : I2C connect




## 16 : CMBus connector




17 : SPI TPM connector



18 : GPIO connector




**19 : Power Button Connector**




**PWRBTN\_EXT**





**20 : Stereo Out Connector**





**STEREO\_OUT**



21 : Front Panel connector



22 : Front Panel Audio (Line Out / Mic) connector



## 5 System Resources

### 5.1 Intel® Elkhart Lake SoC

Intel® Atom™ x6425E Processor(12C, 1.5M Cache, up to 3.00 GHz)

### 5.2 Main Memory

PEB-2274 provides 1 x 204-pin SO-DIMM sockets which supports DDR4 non-ECC memory. The maximum memory can be up to 32GB. Memory clock and related settings can be detected by BIOS via SPD interface.

Watch out the contact and lock integrity of memory module with socket, it will impact on the system reliability. Follow normal procedures to install memory module into memory socket. Before locking, make sure that all modules have been fully inserted into the card slots.

### 5.3 Installing the Single Board Computer

To install your PEB-2274 into standard chassis or proprietary environment, please perform the following:

Step 1 : Check all jumpers setting on proper position

Step 2 : Install and configure memory module on right position

Step 3 : Place PEB-2274 into the dedicated position in the system

Step 4 : Attach cables to existing peripheral devices and secure it

#### **WARNING**

Please ensure that motherboard is properly inserted and fixed by mechanism.

### 5.3.1 Chipset Component Driver

The PEB-2274 build with Intel® Atom™ processor x6425E . It's a new chipset that some old operating systems might not be able to recognize. To overcome this compatibility issue, for Windows Operating Systems such as Windows 10, please install its INF before any of other Drivers are installed.

### 5.3.2 Intel® UHD Graphics

PEB-2274 has integrated Intel® UHD Graphics for 10<sup>th</sup> Gen Intel I® Processors.

Processor Graphics indicates graphics processing circuitry integrated into the processor, providing the graphics, compute, media, and display capabilities. Intel® HD Graphics, Iris™ Graphics, Iris Plus Graphics, and Iris Pro Graphics deliver enhanced media conversion, fast frame rates, and 4K Ultra HD (UHD) video. PEB-2274 supports LVDS, DP, HDMI display output. This combination makes PEB-2274 an excellent performance hardware.

### 5.3.3 Intel LAN I210IT Gigabit Ethernet Controller

- Intel I210IT Gigabit Ethernet controller and 2x RJ45 connectors on rear I/O

## 6 BIOS Setup Items

### 6.1 Introduction

The following section describes the BIOS setup program. The BIOS setup program can be used to view and change the BIOS settings for the module. Only experienced users should change the default BIOS settings.

### 6.2 BIOS Setup


Power on the computer and the system will start POST (Power on Self Test) process. When the message below appears on the screen, press <Delete> or <ESC> key will enter BIOS setup screen.

#### **Press<Delete> or <ESC> to enter SETUP**

If the message disappears before responding and still wish to enter Setup, please restart the system by turning it OFF and On or pressing the RESET button. It can be also restarted by pressing <Ctrl>, <Alt>, and <Delete> keys on keyboard simultaneously.


#### **Press <F1> to Run General Help or Resume**

The BIOS setup program provides a General Help screen. The menu can be easily called up from any menu by pressing <F1>. The Help screen lists all the possible keys to use and the selections for the highlighted item. Press <Esc> to exit the Help Screen.



## 6.2.1 Main


Use this menu for basic system configurations, such as time, date etc.



| Feature            | Description                                                                                   | Options |
|--------------------|-----------------------------------------------------------------------------------------------|---------|
| <b>System Date</b> | The date format is <Day>, <Month> <Date> <Year>. Use [ + ] or [ - ] to configure system Date. |         |
| <b>System Time</b> | The time format is <Hour> <Minute> <Second>. Use [ + ] or [ - ] to configure system Time.     |         |

## 6.2.2 Configuration

Use this menu to set up the items of special enhanced features



**PCH-FW Configuration**  
Configure Management Engine Technology Parameters




| Feature              | Description                                                                                                                                                          | Options    |
|----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| TPM Device Selection | Selects TPM device: PTT or dTPM. PTT-Enable PTT in SkuMgr dTPM1.2 –Disables PTT in SkuMgr Warning! PTT/ dTPM will be disabled and all data saved on it will be lost. | ★dTPM, PTT |

Trusted Computing  
Trusted Computing Settings




| Feature                 | Description                                                                                                                                           | Options          |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| Security Device Support | Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available. | ★Enable, Disable |

**CPU Configuration****CPU Configuration Parameters**


| Feature                                     | Description                                                                                             | Options            |
|---------------------------------------------|---------------------------------------------------------------------------------------------------------|--------------------|
| <b>Intel (VMX)Virtualization Technology</b> | When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology. | ★Enabled ,Disabled |
| <b>VT-d</b>                                 | VT-d capability                                                                                         | ★Enabled ,Disabled |

CPU- Power Management Control  
CPU- Power Management Control Options




| Feature                                 | Description                                                                                                                                                                                                                                                                                                    | Options            |
|-----------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|
| <b>Intel(R) SpeedStep(tm)</b>           | Allows more than two frequency ranges to be supported.                                                                                                                                                                                                                                                         | ★Enabled ,Disabled |
| <b>Intel(R) Speed Shift Technology</b>  | Enable/Disable Intel(R) Speed Shift Technology support. Enabling will expose the CPPC v2 interface to allow for hardware controlled P-states.                                                                                                                                                                  | ★Enabled ,Disabled |
| <b>Turbo Mode</b>                       | Enable/Disable processor Turbo Mode(requires EMTTM enabled too). AUTO means enabled.                                                                                                                                                                                                                           | ★Enabled ,Disabled |
| <b>C states</b>                         | Enable/Disable CPU Power Management. Allows CPU to go to C states when it's not 100% utilized.                                                                                                                                                                                                                 | ★Enabled ,Disabled |
| <b>Enhanced C-states</b>                | Enable/Disable C1E. When enabled, CPU will switch to minimum speed when all cores enter C-State.                                                                                                                                                                                                               | ★Enabled ,Disabled |
| <b>Power Limit 1 Override</b>           | Enable/Disable Power Limit 1 override. If this option is disabled, BIOS will program the default values for power Limit 1 and Power Limit 1 Time Window.                                                                                                                                                       | ★Disabled, Enabled |
| <b>Power Limit 1 Override [Enable ]</b> |                                                                                                                                                                                                                                                                                                                |                    |
| <b>Power Limit 1</b>                    | Power Limit 1 in Milli Watts. BIOS will round to the nearest 1/8W when programming. 0=no custom override. For 12.50W, enter 12500. Overclocking SKU: Value must be between Max and Min Power Limits(specified by PACKAGE_POWER_SKU_MSR). Other SKUs: This value must be between Min Power Limit and TDP Limit. | ★0                 |
| <b>Power Limit 2 Override</b>           | Enable/Disable Power Limit 1 override. If this option is disabled, BIOS will program the default values for Power Limit 2 .                                                                                                                                                                                    | ★Enabled ,Disabled |
| <b>Power Limit 2</b>                    | Power Limit 2 value in Milli Watts. BIOS will round to the nearest 1/8W when programming. If value is 0, BIOS will program this value as 1.25*TDP. For 12.50w, enter 12500. Processor applies control policies such that the package power does not exceed this limit.                                         | ★0                 |

Graphics Configuration  
Graphics Configuration



| Feature             | Description                             | Options            |
|---------------------|-----------------------------------------|--------------------|
| RC6(Render Standby) | Check to enable render standby support. | ★Enabled, Disabled |

Super IO Configuration  
NCT6126D Super IO Configuration




| Feature                     | Description                          | Options |
|-----------------------------|--------------------------------------|---------|
| Serial Port 1 Configuration | Set Parameters of Serial Port1(COMA) |         |
| Serial Port 2 Configuration | Set Parameters of Serial Port2(COMB) |         |
| Serial Port 3 Configuration | Set Parameters of Serial Port3(COMC) |         |
| Serial Port 4 Configuration | Set Parameters of Serial Port4(COMD) |         |
| Serial Port 5 Configuration | Set Parameters of Serial Port5(COME) |         |
| Serial Port 6 Configuration | Set Parameters of Serial Port6(COMF) |         |

Serial Port 1 Configuration




| Feature      | Description                             | Options            |
|--------------|-----------------------------------------|--------------------|
| Serial Port  | Enable or Disable Serial Port (COM)     | ★Enabled ,Disabled |
| COM1 Control | Select COM1 mode. RS232, RS422 or RS485 | ★RS232,RS422,RS485 |

Serial Port 2 Configuration




| Feature      | Description                             | Options            |
|--------------|-----------------------------------------|--------------------|
| Serial Port  | Enable or Disable Serial Port (COM)     | ★Enabled ,Disabled |
| COM2 Control | Select COM2 mode. RS232, RS422 or RS485 | ★RS232,RS422,RS485 |

Serial Port 3 Configuration




| Feature     | Description                         | Options            |
|-------------|-------------------------------------|--------------------|
| Serial Port | Enable or Disable Serial Port (COM) | ★Enabled ,Disabled |

Serial Port 4 Configuration



| Feature     | Description                         | Options            |
|-------------|-------------------------------------|--------------------|
| Serial Port | Enable or Disable Serial Port (COM) | ★Enabled ,Disabled |

Serial Port 5 Configuration



| Feature     | Description                         | Options            |
|-------------|-------------------------------------|--------------------|
| Serial Port | Enable or Disable Serial Port (COM) | ★Enabled ,Disabled |


Serial Port 6 Configuration



| Feature     | Description                         | Options            |
|-------------|-------------------------------------|--------------------|
| Serial Port | Enable or Disable Serial Port (COM) | ★Enabled ,Disabled |

Serial Console Redirection

Serial Console Redirection



| Feature                       | Description                                                                                                                                                                  | Options            |
|-------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|
| Console Redirection           | Console Redirection Enable or Disable                                                                                                                                        | ★Disabled, Enabled |
| Console Redirection [Enabled] |                                                                                                                                                                              |                    |
| Console Redirection Settings  | The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings. |                    |

Console Redirection Settings

Aptio Setup - AMI

Advanced

COM1  
Console Redirection Settings

Terminal Type

[ANSI]

Bits per second

[115200]

Data Bits

[8]

Parity

[None]

Stop Bits

[1]

Flow Control

[None]

VT-UTF8 Combo Key Support

[Enabled]

Recorder Mode

[Disabled]

Resolution 100x31

[Disabled]

Putty KeyPad

[VT100]

Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.

↔: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults


F4: Save & Exit

ESC: Exit

Version 2.22.1282 Copyright (C) 2024 AMI

| Feature                          | Description                                                                                                                                                                                                                                                                                                                       | Options                                 |
|----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------|
| <b>Terminal Type</b>             | Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.                                                                                                                               | ★ANSI, VT100, VT100+, VT-UTF8           |
| <b>Bits per second</b>           | Select Serial port transmission speed. The speed must be matched on other side. Long or noisy lines may require lower speeds.                                                                                                                                                                                                     | ★115200, 9600, 19200, 38400, 57600      |
| <b>Data bits</b>                 | Data bits                                                                                                                                                                                                                                                                                                                         | ★8, 7                                   |
| <b>Parity</b>                    | A parity bit can be sent with the data bits to detect some transmission errors. Even: parity bit is 0 if the num of 1's in the data bits is even. Odd: parity bit is 0 if num of 1's in the data bits is odd. Mark: parity bit is always 1. Space Parity bit is always 0. Mark and Space Parity do not allow for error detection. | ★None, Even, Odd, Mark, Space           |
| <b>Stop Bits</b>                 | Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.                                                                                                                                  | ★1,2                                    |
| <b>Flow Control</b>              | Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.                 | ★None, Hardware RTS/CTS                 |
| <b>VT-UTFB Combo Key Support</b> | Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals                                                                                                                                                                                                                                                                   | ★Enabled, Disabled                      |
| <b>Recorder Mode</b>             | With this mode enabled only text will be sent. This is to capture Terminal data.                                                                                                                                                                                                                                                  | ★Disabled, Enabled                      |
| <b>Resolution 100x31</b>         | Enables or disables extended terminal resolution                                                                                                                                                                                                                                                                                  | ★Disabled, Enabled                      |
| <b>Putty KeyPad</b>              | Select FunctionKey and KeyPad on Putty                                                                                                                                                                                                                                                                                            | ★VT100, LINUX,XTERMR6, SCO, ESCN, VT400 |


SATA Configuration  
SATA Device Options Settings



| Feature                    | Description                                | Options             |
|----------------------------|--------------------------------------------|---------------------|
| <b>SATA Controller(s)</b>  | Enable/Disable SATA Device.                | ★Enabled , Disabled |
| <b>SATA Mode Selection</b> | Determines how SATA controller(s) operate. | ★AHCI               |
| <b>M.2 M-Key(SATA)</b>     | Enable or Disable SATA Port                | ★Enabled , Disabled |
| <b>SATA6G</b>              | Enable or Disable SATA Port                | ★Enabled, Disabled  |

Network Stack Configuration

Network Stack Settings



| Feature                 | Description                                                                                    | Options            |
|-------------------------|------------------------------------------------------------------------------------------------|--------------------|
| Network Stack           | Enable/ Disable UEFI Network Stack                                                             | ★Disabled, Enabled |
| Network Stack [Enabled] |                                                                                                |                    |
| Ipv4 PXE Support        | Enable/Disable IPv4 PXE boot support. If disable, IPv4 PXE boot support will not be available. | ★Disabled, Enabled |
| Ipv6 PXE Support        | Enable/Disable IPv6 PXE boot support. If disable, IPv6 PXE boot support will not be available. | ★Disabled, Enabled |

USB Configuration  
USB Configuration Setting

Aptio Setup - AMI

Advanced

USB Configuration

USB Module Version25

USB Controllers:  
1 XHCI

USB Devices:  
1 Drive, 1 Keyboard

XHCI Hand-off[Enabled]

USB Mass Storage Driver Support[Enabled]

U32G2\_1[Enabled]

U32G2\_2[Enabled]

U32G2\_3[Enabled]

U32G2\_4[Enabled]

USB1[Enabled]

USB2[Enabled]

This is a workaround for OSes without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

↔: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults


F4: Save & Exit

ESC: Exit

Version 2.22.1282 Copyright (C) 2024 AMI

| Feature                                | Description                                                                                                                                            | Options            |
|----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|
| <b>XHCI Hand-off</b>                   | This is a workaround for OSeS without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver                                | ★Enabled, Disabled |
| <b>USB Mass Storage Driver Support</b> | Enable/Disable USB Mass Storage Driver Support                                                                                                         | ★Enabled, Disabled |
| <b>U32G2_1~4</b>                       | Enable/Disable this USB Physical Connector (physical port). Once disabled, any USB devices plug into the connector will not be detected by BIOS or OS. | ★Enabled, Disabled |
| <b>USB1~2</b>                          | Enable/Disable this USB Physical Connector (Physical port). Once disabled, any USB devices plug into the connector will not be detected by BIOS or OS. | ★Enabled, Disabled |

**NVMe Configuration**  
NVMe Device Option Settings



Onboard Devices Configuration

Onboard Devices Configuration

Aptio Setup - AMI

Advanced

|                                |            |                                                                                                                                                |
|--------------------------------|------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| HD Audio                       | [Enabled]  | Control Detection of the HD-Audio device.<br>Disabled = HDA will be unconditionally disabled<br>Enabled = HDA will be unconditionally enabled. |
| Intel I210-IT LAN 1 Controller | [Enabled]  |                                                                                                                                                |
| Intel I210-IT LAN 2 Controller | [Enabled]  |                                                                                                                                                |
| M.2 M-Key(PCIE)                | [Enabled]  |                                                                                                                                                |
| M.2 B-Key(USB)                 | [Enabled]  |                                                                                                                                                |
| I2C Controller                 | [Enabled]  |                                                                                                                                                |
| In-Band ECC                    | [Disabled] |                                                                                                                                                |
| M.2(WiFi)                      |            |                                                                                                                                                |
| PCIE Port(WiFi)                | [Enabled]  |                                                                                                                                                |
| USB Port(BT)                   | [Enabled]  |                                                                                                                                                |

↔: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

Version 2.22.1282 Copyright (C) 2024 AMI

| Feature                       | Description                                                                                                                                   | Options            |
|-------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|--------------------|
| HD Audio                      | Control Detection of the HD-Audio device.<br>Disabled= HDA will be unconditionally disabled.<br>Enabled= HDA will be unconditionally enabled. | ★Enabled, Disabled |
| Intel I210-IT LAN1 Controller | Enable/Disable Intel I210-IT LAN1 Controller                                                                                                  | ★Enabled, Disabled |
| Intel I210-IT LAN2 Controller | Enable/Disable Intel I210-IT LAN2 Controller                                                                                                  | ★Enabled, Disabled |
| M.2 M-Key(PCIE)               | Enable/Disable M.2 M-Key(PCIE)                                                                                                                | ★Enabled, Disabled |
| M.2 B-Key(USB)                | Enable/Disable M.2 B-Key(USB)                                                                                                                 | ★Enabled, Disabled |
| I2C Controller                | Enable/Disable I2C Controller                                                                                                                 | ★Enabled, Disabled |
| In-Band ECC                   | Enable/Disable In-Band ECC                                                                                                                    | ★Disabled, Enabled |
| PCIE Port(WiFi)               | Enable/Disable M.2 WiFi (PCIE Port) Controller                                                                                                | ★Enabled, Disabled |
| USB Port (BT)                 | Enable/Disable M.2 BT(USB Port) Controller                                                                                                    | ★Enabled, Disabled |

APM Configuration  
Advance Power Management

Aptio Setup - AMI

Advanced

APM Configuration

ErP Ready

[Disabled]

Restore AC Power Loss

[S5 State]

Power On By PCIE

[Disabled]

Power On By Ring

[Disabled]

Power On By RTC

[Weekly event]

Alarm day of Week

[Sunday]

Alarm Time

Wake up hour

0

Wake up minute

0

Wake up second

0

Allow BIOS to switch off some power at S4/S5 to get the system ready for ErP requirement. When set to Enabled, all other PME options will be switched off.

↔: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults


F4: Save & Exit

ESC: Exit

Version 2.22.1282 Copyright (C) 2024 AMI


| Feature                      | Description                                                                                                                                                                          | Options                                                           |
|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------|
| <b>ErP Ready</b>             | Allow BIOS to switch off some power at S4/S5 to get the system ready for ErP requirement. When set to Enabled, all other PME options will be switched off.                           | ★Disabled, Enabled                                                |
| <b>Restore AC Power Loss</b> | Select AC power state when power is re-applied after a power failure.                                                                                                                | ★S5 State, S0 State                                               |
| <b>Power On By PCIE</b>      | Enable or disable the Wake-on-LAN function of the onboard LAN controller or other installed PCIE LAN devices.                                                                        | ★Disabled, Enabled                                                |
| <b>Power On By Ring</b>      | Power On By Ring.                                                                                                                                                                    | ★Disabled, Enabled                                                |
| <b>Power On By RTC</b>       | Select whether to enable Wake Up on Alarm, to turn on your system on a special day of the week or daily.<br>NOTE: Values in these fields may be overwritten by the operating system. | ★Disabled, Single event, Daily event, Weekly event, Monthly event |
| <b>Alarm day of Week</b>     | Select the day of the week when the system is to wake up.                                                                                                                            | ★Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday   |
| <b>Day of the Month</b>      | RTC Alarm Date (Days)                                                                                                                                                                | ★15                                                               |
| <b>Wake up hour</b>          | Select 0-23 For example enter 3 for 3am and 15 for 3 pm.                                                                                                                             | ★0                                                                |
| <b>Wake up minute</b>        | Select 0-59 for Minute.                                                                                                                                                              | ★0                                                                |
| <b>Wake up second</b>        | Select 0-59 for Second.                                                                                                                                                              | ★0                                                                |

Watchdog Timer



| Feature             | Description                         | Options                    |
|---------------------|-------------------------------------|----------------------------|
| Watchdog Support    | Enable/Disable Watchdog Support.    | ★ Enable, Disabled         |
| Watchdog Count mode | Select Watchdog Timer I count mode. | ★ Second Mode, Minute Mode |
| Watchdog Timer      | Watchdog Timer I Time-out value.    | ★ 120                      |


**EZ-Flash**  
EZ-Flash



| Feature             | Description         | Options |
|---------------------|---------------------|---------|
| Enter Ez-Flash mode | Enter Ez-Flash mode |         |

LVDS Configuration


LVDS Configuration



| Feature        | Description                                                                                                                                     | Options                   |
|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------|
| IGD Flat Panel | Enable or disable IGD video output to onboard LVDS.<br>Auto: Enable IGD video output to onboard LVDS when the panel is present, and vice versa. | ★Auto, Enabled, Disabled, |


|                                    |                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                          |
|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>All-in-One Chassis</b>          | Select All-in-One(AiO)chassis(if applicable) for simplified AiO configuration.<br>Warning: Incorrect selection of AiO chassis may result in incorrect operation or potential damage to AiO chassis hardware. | ★None,1920*1080 LVDS1,<br>1920*1080 LVDS2,<br>1920*1080 LVDS3,<br>1600*900 LVDS4,                                                                                                                                                                                                        |
| <b>EDID Data Source</b>            | EDID Data Source                                                                                                                                                                                             | ★Pre-defined, Flat Panel Display                                                                                                                                                                                                                                                         |
| <b>Pre-Defined LVDS Panel Type</b> | Select LVDS panel used by Internal Graphics Device by selecting the appropriate setup item.                                                                                                                  | ★VBIOS Default,<br>640x480,<br>800x600,<br>1024x768,<br>1280x1024,<br>1400x1050(RB) LVDS1,<br>1400x1050 LVDS2,<br>1600x1200 LVDS,<br>1366x768 LVDS,<br>1680x1050,<br>1920x1200,<br>1440x900 LVDS,<br>1600x900 LVDS,<br>1024x768 LVDS2,<br>1280x800,<br>1920x1080 LVDS,<br>2048x1536 LVDS |
| <b>Inverter Polarity</b>           | Inverter board polarity<br>Normal: PWM=0%(Dim)<br>Inverted: PWM=0%(Bright)<br>Consult inverter board specifications for proper value.                                                                        | ★Normal, Inverted                                                                                                                                                                                                                                                                        |
| <b>Channel Select</b>              | Channel Select.                                                                                                                                                                                              | ★Single Channel. Dual Channel                                                                                                                                                                                                                                                            |
| <b>Mode Select</b>                 | Mode Select.                                                                                                                                                                                                 | ★VESA 8bit, JEIDA, VESA 6bit,<br>VESA 10bit                                                                                                                                                                                                                                              |

6.2.3 H/W Monitor




| Feature        | Description           | Options                         |
|----------------|-----------------------|---------------------------------|
| Smart Fan Mode | Smart Fan Mode Select | ★ Normal, Disabled, Manual Mode |

**Smart Fan Function**  
Smart Fan Function setting



| Feature                   | Description                                         | Options |
|---------------------------|-----------------------------------------------------|---------|
| Chassis Fan Temperature 1 | The value of temperature 1.                         | ★25     |
| Chassis Fan Temperature 2 | The value of temperature 2.                         | ★35     |
| Chassis Fan Temperature 3 | The value of temperature 3.                         | ★45     |
| Chassis Fan Temperature 4 | The value of temperature 4.                         | ★55     |
| Chassis Fan FD/RPM 1      | The value of Fan Duty/RPM 1 when temperature is T1. | ★140    |
| Chassis Fan FD/RPM 2      | The value of Fan Duty/RPM 2 when temperature is T2. | ★170    |
| Chassis Fan FD/RPM 3      | The value of Fan Duty/RPM 3 when temperature is T3. | ★200    |
| Chassis Fan FD/RPM 4      | The value of Fan Duty/RPM 4 when temperature is T4. | ★230    |

### **6.2.4 Security**




| Feature                | Description                 | Options |
|------------------------|-----------------------------|---------|
| Administrator Password | Set Administrator password. |         |
| User Password          | Set User Password           |         |

Secure Boot  
Secure Boot configuration




| Feature          | Description                                                                                                                                                           | Options             |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------|
| Secure Boot      | Secure Boot feature is Active if Secure Boot is Enabled, Platform Key (PK) is enrolled and the System is in User mode. The mode change requires platform reset.       | ★ Disabled, Enabled |
| Secure Boot Mode | Secure Boot Mode options: Standard or Custom. In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication | ★ Custom ,Standard  |

Key Management



| Feature               | Description                                               | Options |
|-----------------------|-----------------------------------------------------------|---------|
| Platform Key(PK)      | Enroll Factory Defaults or load certificates from a file: |         |
| Key Exchange Keys     | 1.Public Key Certificate:                                 |         |
| Authorized Signatures | a)EFI_SIGNATURE_LIST                                      |         |
| Forbidden Signatures  | b) EFI_CERT_X509 (DER)                                    |         |
|                       | c) EFI_CERT_RSA2048 (bin)                                 |         |
|                       | d)EFI_CERT_SHAXXX                                         |         |
|                       | 2.Authenticated UEFI Variable                             |         |
|                       | 3.EFI PE/COFF Image(SHA256)                               |         |
|                       | Key Source: Factory, External, Mixed                      |         |


6.2.5 Boot



| Feature                     | Description                                                                                 | Options             |
|-----------------------------|---------------------------------------------------------------------------------------------|---------------------|
| <b>CHASSIS INTRUDE</b>      | Enable/Disable CHASSIS INTRUDE                                                              | ★ Disabled, Enabled |
| <b>Setup Prompt Timeout</b> | Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting. | ★ 1                 |

|                             |                                                                                                                                                     |                                                        |
|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|
| <b>Post Time Delay</b>      | Delay for specific situation needs. For example, HDD spin up time (Delay time=value*500ms)                                                          | ★0                                                     |
| <b>Bootup NumLock State</b> | Select the keyboard NumLock state                                                                                                                   | ★On, Off                                               |
| <b>Quiet Boot</b>           | Enables or disables Quiet Boot option                                                                                                               | ★Enabled, Disabled                                     |
| <b>Fast Boot</b>            | Enables or disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options. | ★Disabled, Enabled                                     |
| <b>Boot Option #1~#5</b>    | Sets the system boot order                                                                                                                          | ★Hard Disk, NVME, CD/DVD,USB Device, Network, Disabled |

6.2.6 Save & Exit



| Feature                  | Description                                   | Options |
|--------------------------|-----------------------------------------------|---------|
| Save Changes and Exit    | Exit system setup after saving the changes.   |         |
| Discard Changes and Exit | Exit system setup without saving any changes. |         |
| Save Changes and Reset   | Reset the system after saving the changes.    |         |

|                                  |                                                          |  |
|----------------------------------|----------------------------------------------------------|--|
| <b>Discard Changes and Reset</b> | Rest system setup without saving any changes.            |  |
| <b>Save Changes</b>              | Save Changes done so far to any of the setup options.    |  |
| <b>Discard Changes</b>           | Discard Changes done so far to any of the setup options. |  |
| <b>Restore Defaults</b>          | Restore/Load Default values for all the setup options.   |  |
| <b>Save as Use Defaults</b>      | Save the changes done so far as User Defaults            |  |
| <b>Restore User Defaults</b>     | Restore the User Defaults to all the setup options.      |  |

## 7 Troubleshooting


This section provides a few useful tips to quickly get PEB-2274 running with success. This section will primarily focus on system integration issues, in terms of BIOS setting, and OS diagnostics.


### 7.1 Hardware Quick Installation

#### DC Jack Power

There is one method to connect the power of PEB-2274 which is 12V DC Jack (DC-IN).

| j. DC_PWR |        |     |        |
|-----------|--------|-----|--------|
| Pin       | Signal | Pin | Signal |
| 1         | GND    | 3   | V+     |
| 2         | V+     | 4   | GND    |






## Serial ATA

Unlike IDE bus, each Serial ATA channel can only connect to one SATA hard disk at a time;

The installation of Serial ATA is simpler and easier than IDE, because SATA hard disk doesn't require setting up Master and Slave, which can reduce mistake of hardware installation.



PEB-2274 can support one SATA interface (SATAIII, 6.0Gb/s) on board. It has SATA ports on board.

## 7.2 BIOS Setting

It is assumed that users have correctly adopted modules and connected all the devices cables required before turning on DC power. DDR4 SO-DIMM Memory, keyboard, mouse, SATA hard disk, DP connector, power cable of the device, ATX accessories are good examples that deserve attention. With no assurance of properly and correctly accommodating these modules and devices, it is very possible to encounter system failures that result in malfunction of any device.

To make sure that you have a successful start with PEB-2274, it is recommended, when going with the boot-up sequence, to hit "delete " or " Esc" key and enter

the BIOS setup menu to tune up a stable BIOS configuration so that you can wake up your system far well.

### **Loading the default optimal setting**

When prompted with the main setup menu, please scroll down to “Restore Defaults”, press “Enter” and select “Yes” to load default optimal BIOS setup. This will force your BIOS setting back to the initial factory configurations. It is recommended to do this so you can be sure the system is running with the BIOS setting that Portwell has highly endorsed. As a matter of fact, users can load the default BIOS setting at any time when system appears to be unstable in boot up sequence.


## **7.3 FAQ**

### **Information & Support**

**Question:** I forgot my password of system BIOS, what am I supposed to do?

**Answer:** You can switch off your power supply then find the 2-pin CLRTC on the PEB-2274 board .Then Use a metal object such as a screwdriver to short the two pins and wait 5 seconds to clean your password then to switch on your power supply.

**Clear CMOS header (2-pin CLRTC) : CMOS Setting**



## PEB-2274

**Question:** How to update the BIOS file of PEB-2274?


**Answer:** 1. Please visit web site of **Portwell download center** as below hyperlink


<https://www.portwell.com.tw/support-center/download-center/>

2. Select “**Search download**” and type the keyword “**PEB-2274**”.


3. Find the “**BIOS**” page and download the ROM file and unzip file to USB flash drive (FAT 32 / 16 format ).


4. Boot into BIOS and switch to “**Advanced**” page then select “**EZ-Flash**”.






5. Enter EZ-Flash mode, Select the USB Drive and Click the BIOS file then start updating BIOS.





6. When you see the “**BIOS updated successfully**” message, which means the BIOS update processes finished. Please cut the AC power of and **wait for 10 seconds** before powering on.



## PEB-2274

**Question:** What are the display options while using PEB-2274 board?

**Answer:** - The PEB-2274 supports HDMI 、 DP 、 LVDS display output.

Note:

Please visit our Download Center to get the Catalog, User manual, BIOS, and Driver files.

<https://www.portwell.com.tw/support-center/download-center/>

If you have other additional technical information or request which is not covered in this manual, please fill in the technical request form as below hyperlink.

<https://www.portwell.com.tw/support-center/technical-request/>

We will do our best to provide a suggestion or solution for you.

Thanks

## 8 Portwell Software Service

1. If you have customized requirements of BIOS, you can contact person of our company or branch.
2. If you have requirements of WDT 、GPIO APP, you can contact our headquarter or branch, and we can render you assistance on developing.

|                                                                    |                                                                        |
|--------------------------------------------------------------------|------------------------------------------------------------------------|
| Portwell Worldwide:                                                |                                                                        |
| <a href="#">Portwell, Inc.</a>                                     | E-mail: <a href="mailto:info@portwell.com.tw">info@portwell.com.tw</a> |
| <a href="#">Shanghai Portwell (China)</a>                          | E-mail: <a href="mailto:info@portwell.com.cn">info@portwell.com.cn</a> |
| <a href="#">Portwell Japan, Inc (Tokyo/Osaka)</a>                  | E-mail: <a href="mailto:info@portwell.co.jp">info@portwell.co.jp</a>   |
| <a href="#">American Portwell Technology (USA)</a>                 | E-mail: <a href="mailto:info@portwell.com">info@portwell.com</a>       |
| <a href="#">European Portwell Technology (Netherlands)</a>         | E-mail: <a href="mailto:info@portwell.eu">info@portwell.eu</a>         |
| <a href="#">Portwell UK Ltd. (UK)</a>                              | E-mail: <a href="mailto:info@portwell.eu">info@portwell.eu</a>         |
| <a href="#">KIOSK Embedded Systems GmbH</a>                        | E-mail: <a href="mailto:info@portwell.eu">info@portwell.eu</a>         |
| <a href="#">Portwell India Technology Private Limited. (India)</a> | E-mail: <a href="mailto:enquiry@portwell.in">enquiry@portwell.in</a>   |
| <a href="#">Portwell Korea, Inc. (Korea)</a>                       | E-mail: <a href="mailto:info@portwell.co.kr">info@portwell.co.kr</a>   |

## 9 Industry Specifications

The list below provides links to industry specifications that apply to Portwell modules.

Low Pin Count Interface Specification, Revision 1.0 (LPC) <http://www.intel.com/design/chipsets/industry/lpc.htm>

Universal Serial Bus (USB) Specification, Revision 2.0 <http://www.usb.org/home>

PCI Specification, Revision 2.3 <https://www.pcisig.com/specifications>

Serial ATA Specification, Revision 3.0 <http://www.serialata.org/>

PCI Express Base Specification, Revision 2.0 <https://www.pcisig.com/specifications>