

DTEC-C012  
DTEC-C014  
DTEC-C016

Embedded Rugged Fan-less System  
Featuring 12<sup>th</sup> Gen Intel® Core™ i3/i5/i7 Mobile  
Processors



## User's Manual

Version 2.0

Copyright © Portwell, Inc., 2023. All rights reserved.  
All other brand names are registered trademarks of their respective owners.

Manufacturer Address Information:  
No.242, Bo-Ai St., Shu-Lin Dist, New Taipei City 238, Taiwan

# Table of Contents

## How to Use This Manual

|                                                                      |             |
|----------------------------------------------------------------------|-------------|
| <b>Chapter 1 System Overview</b>                                     | <b>1-1</b>  |
| - 1.1 Introduction                                                   | 1-1         |
| - 1.2 Check List                                                     | 1-2         |
| - 1.3 Product Specification                                          | 1-2         |
| - 1.4 Mechanical Dimension                                           | 1-3         |
| - 1.5 Product Environment Information                                | 1-4         |
| - 1.6 Adaptor Information                                            | 1-4         |
| <b>Chapter 2 System Installation</b>                                 | <b>2-1</b>  |
| - 2.1 CPU and Memory module Installation                             | 2-1         |
| - 2.2 Wi-Fi module Installation                                      | 2-4         |
| - 2.3 I/O Interfaces                                                 | 2-10        |
| - 2.3.1 Front View                                                   | 2-10        |
| - 2.3.2 Rear View                                                    | 2-11        |
| - 2.4 Getting Started                                                | 2-13        |
| <b>Chapter 3 BIOS Setup Information</b>                              | <b>3-11</b> |
| - 3.1 Main                                                           | 3-12        |
| - 3.2 Security                                                       | 3-21        |
| - 3.3 Boot                                                           | 3-31        |
| - 3.4 Save & Exit                                                    | 3-41        |
| <b>Chapter 4 Important Instructions</b>                              | <b>4-1</b>  |
| - 4.1 Note on the Warranty                                           | 4-1         |
| - 4.2 Exclusion of Accident Liability Obligation                     | 4-1         |
| - 4.3 Liability Limitations / Exemption from the Warranty Obligation | 4-1         |
| - 4.4 Declaration of Conformity                                      | 4-1         |

## How to Use This Manual

The manual describes how to configure your DTEC-C012 & DTEC-C014 & DTEC-C016 system to meet various operating requirements. It is divided into four chapters, with each chapter addressing a basic concept and operation of Embedded System.

**Chapter 1: System Overview.** Present what you have in the box and give you an overview of the product specifications and basic system architecture for this embedded system.

**Chapter 2: System Installation.** Show the definitions and locations of all the interfaces and describe a proper installation guide so that you can easily configure your system.

**Chapter 3: BIOS Setup Information.** Specify the meaning of each setup parameters, how to get advanced BIOS performance and update new BIOS. In addition, POST checkpoint list will give users some guidelines of trouble-shooting.

**Chapter 4: Important Instructions.** Indicate some instructions which must be carefully followed when the embedded system is used.

The content of this manual is subject to change without prior notice. These changes will be incorporated in new editions of the document. The vendor may make supplement or change in the products described in this document at any time.

## Revision History

| Revision | Date    | Details of Change(s) |
|----------|---------|----------------------|
| V1.0     | 2023/08 | Initial Release      |

# Chapter 1

## System Overview

### 1.1 Introduction

Portwell introduces the DTEC-C012, DTEC-C014, and DTEC-C016, stylish fan-less medical systems with exceptional performance, making them ideal solutions for hospitals. These rugged systems are equipped with embedded boards based on the 12th Generation Intel® Core™ Processor, ensuring improved 3D graphics performance and faster 4K encode and decode operations.

The DTEC-C012, DTEC-C014, and DTEC-C016 systems boast a range of features, including a single channel SO-DIMM DDR5 4800 MHz up to 64GB, 4x USB 3.2 and 5x USB 2.0 ports, and 1x HDMI plus 1x DP supporting a maximum resolution of up to 8K. They also offer versatile storage options including 1x SATA III port and 1x M.2 slot supporting NVMe. The compact chassis platform measuring 152(W) x 196(D) x 44(H) mm includes Wi-Fi, Bluetooth module, and antenna, ensuring seamless communication and wireless connectivity. Additionally, the inclusion of 1x RJ45 COM port makes it a perfect solution for controlling medical equipment.

The DTEC-C012, DTEC-C014, and DTEC-C016 by Portwell deliver robust performance surpassing their predecessors, with a thermal design power (TDP) of under 15W. These systems are designed to support a wide voltage range of power input from 12V to 24V, making them suitable for rugged applications.

Featuring ingenious mechanical design and high processing capabilities, thanks to the Intel® Core™ processor with ten-core processing power, the fan-less medical grade DTEC-C012, DTEC-C014, and DTEC-C016 systems are robust solutions for telehealth, digital signage, automation, IoT, and control box applications.

## 1.2 Check List

The DTEC-C012, DTEC-C014, and DTEC-C016 package should cover the following basic items:

- ✓ One BOX PC System
- ✓ One Adapter

If any of these items is damaged or missing, please contact your vendor and keep all packing materials for future replacement and maintenance.

## 1.3 Product Specification

### DTEC-C012:


| System    |                                                               |
|-----------|---------------------------------------------------------------|
| Processor | Intel Alder Lake Core™ i3-1215UE PL1 15W/ PL2 25W             |
| Memory    | 2x SO-DIMM up to 64GB DDR 5 4800                              |
| Storage   | - 1x M.2 NVME with PCIe x4 for SSD<br>- 1x SATA3.0 (6.0 Gb/s) |
| BIOS      | AMI uEFI BIOS (SPI ROM)                                       |
| Expansion | - Optional 1x M.2 2230<br>- support Intel WiFi 6 + BT Module  |

| I/O Interface |                                                              |
|---------------|--------------------------------------------------------------|
| Serial Port   | 2x RJ45 COM port                                             |
| USB           | - 4x USB 3.2 (Type-A)<br>- 5x USB 2.0 (Type-A)               |
| Audio         | Realtek ALC 897 Audio Codec MIC In/Line-out                  |
| Ethernet      | 2x Intel I225 With 2.5G Gigabit LAN                          |
| Display       | - 1x HDMI up to 8K resolution<br>- 1x DP up to 8K resolution |


| Power Supply |                    |
|--------------|--------------------|
| Power Input  | DC 12~24V DC input |

| Mechanical & Environmental |                           |
|----------------------------|---------------------------|
| Operation Temperature      | (-)5°C ~ 40°C             |
| Storage Temperature        | (-)40°C ~ 70°C            |
| Dimension                  | 196(L) x 152(W) x 44(H)mm |

## 1.4 Mechanical Dimension



Front view of the system



Top view of the system

## 1.5 Product Environment Information

|                            |               |
|----------------------------|---------------|
| Relative Humidity          | 0% to 95%     |
| Operating Temperature      | -5°C to 40°C  |
| Atmospheric Pressure       | 70 to 106 kPa |
| Storage Temperature        | -40°C to 70°C |
| Storage Humidity           | 0%-95%        |
| Transportation Temperature | -40°C to 70°C |
| Transportation Humidity    | 0%-95%        |

## 1.6 Adaptor Information


Brand : AOEN

Model name : A1218MD-120100

Spec:

|                  |               |
|------------------|---------------|
| Output Voltage   | 12V           |
| Minimum Load     | 0A            |
| Maximum Load     | 10A           |
| Line Regulation  | +/-1%         |
| Load Regulation  | +/-5%         |
| Voltage Accuracy | 11.4V – 12.6V |
| Ripple & Noise   | 200mV Max.    |

Drawing :



## Chapter 2

### System Installation

This chapter provides you with instructions to set up your system. Definitions and locations of all the interfaces are described so that you can easily configure your system. For more detailed PIN assignment and jumper setting, please refer to user's manual of motherboard.


#### 2.1 Memory & SSD module Installation

|                                                                                                                                             |                                                                                                                                                      |
|---------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Step 1. Loosen the front 5 screws</p>                  | <p>Step 2. Loosen the back 4 screws</p>                           |
| <p>Step 3. Plug out the power button two connectors</p>  | <p>Step 4. Install DDR5 SO-DIMM Memory Module on the system</p>  |

Step 5. 2.5" SSD storage with bracket



Step 6. Lock the SSD with bracket on the main board



Step 7. Assemble the top cover and bottom cover, and lock 4 screws on the rear cover





Step 8. Lock 5 screws on the front cover




## 2.2 Wi-Fi module Installation

Special M.2 design for easy installation and maintenance of Wi-Fi modules and antennas. Optional design offers customers more choices.

|                                                                                                                                                                        |                                                                                                                                              |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Step 1. M.2 Wi-Fi module</b><br>                                                   | <b>Step 2. SMA cable Installation</b><br>                  |
| <b>Step 3. Lock the SMA cable and gasket to the fixed point</b><br> <p>SMA Cable</p> | <b>Step 4. Install the Wi-Fi Module on the system</b><br> |

## 2.3 I/O Interfaces

### 2.3.1 Front View



#### **DC in 12-24V:**

Provide power connection of the system to the main power source via DC power cable or AC/DC power adapter.


#### **Power Button:**

Turn on/ off the Box PC

#### **USB:**

2 x USB 2.0 Type-A ports

### 2.3.2 Rear View



#### **LAN:**

2x Intel I225 With 2.5G Ethernet LAN

#### **USB3.2:**

4x USB3.2 Type A (Universal Serial Bus) ports

#### **USB2.0:**

3x USB2.0 Type A (Universal Serial Bus) ports

#### **HDMI:**

Type A HDMI display output

#### **DP:**

DP display output

#### **Audio:**


Connectors for Mic-In, Line-In and Line-Out

#### **COM port:**

2x RJ-45 COM ports

## 2.4 Getting Started

To start the system, please follow these simple steps: Insert the power jack and press the power button.

|                                                                                                                           |                                                                                    |
|---------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------|
| Step 1. Insert the power connector into the DC input and press the power button to start                                  | Power connector outlook                                                            |
|  <p>DC IN      USB      POWER BUTTON</p> |  |

## Chapter 3

### BIOS Setup Information

#### 3.1 Introduction

The following section describes the BIOS setup program. The BIOS setup program can be used to view and change the BIOS settings for the module. Only experienced users should change the default BIOS settings.

#### 3.2 BIOS Setup


Power on the computer and the system will start POST (Power on Self Test) process. When the message below appears on the screen, press <Delete> or <F2> key will enter BIOS setup screen.

##### **Press<Delete> or <ESC> to enter SETUP**

If the message disappears before responding and still wish to enter Setup, please restart the system by turning it OFF and On or pressing the RESET button. It can be also restarted by pressing <Ctrl>, <Alt>, and <Delete> keys on keyboard simultaneously.

##### **Press <F1> to Run General Help or Resume**


The BIOS setup program provides a General Help screen. The menu can be easily called up from any menu by pressing <F1>. The Help screen lists all the possible keys to use and the selections for the highlighted item. Press <Esc> to exit the Help Screen.



```
↑↓: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Exit
F8: PCI List
F12: Capture Screen
ESC: Exit
```

### ● 3.2.1 Main


Use this menu for basic system configurations, such as time, date etc.



| Feature     | Description                                                                                   |
|-------------|-----------------------------------------------------------------------------------------------|
| System Date | The date format is <Day>, <Month> <Date> <Year>. Use [ + ] or [ - ] to configure system Date. |
| System Time | The time format is <Hour> <Minute> <Second>. Use [ + ] or [ - ] to configure system Time.     |


### ● 3.2.2 Advanced

Use this menu to set up the items of special enhanced features



## CPU Configuration


### CPU Configuration Parameters



| CPU Configuration                     |                                                            |
|---------------------------------------|------------------------------------------------------------|
| Active Performance-Cores              | √All, 1                                                    |
| Hyper-Threading                       | √Enable, Disabled                                          |
| Boot performance mode                 | Max Battery, Max Non-Turbo Performance, √Turbo Performance |
| Intel (VMX) Virtualization Technology | √Enable, Disabled                                          |
| Intel (R) SpeedStep(tm)               | √Enable, Disabled                                          |
| Intel (R) Speed Shift Technology      | √Enable, Disabled                                          |
| Turbo Mode                            | √Enable, Disabled                                          |
| C States                              | Enable, √Disabled                                          |

## Chipset Configuration


### Configuration Chipset feature



| Chipset Configuration          |                    |
|--------------------------------|--------------------|
| VT-d                           | √Enable, Disabled  |
| Above 4GB MMIO BIOS assignment | Enable, √Disabled  |
| HD Audio                       | √Enable, Disabled  |
| Port 80H Redirection           | √LPC Bus, PCIE Bus |
| ME FW Image Re-Flash           | Enable, √Disabled  |
| AMT Configuration              |                    |
| AMT BIOS Features              | √Enable, Disabled  |
| ME Unconfig on RTC Clear       | Enable, √Disabled  |

## SATA Configuration

### Configure SATA Parameters



| SATA Configuration                      |                                     |
|-----------------------------------------|-------------------------------------|
| <b>SATA Controller(S)</b>               | √Enable, Disabled                   |
| <b>Enable VMD controller(RAID mode)</b> | Enable, √Disabled                   |
| <b>Part 1</b>                           | √Enable, Disabled                   |
| <b>Hot Plug</b>                         | Enable, √Disabled                   |
| <b>SATA Device Type</b>                 | √Hard Disk Drive, Solid State Drive |


## LAN Configuration



| LAN Configuration         |                   |
|---------------------------|-------------------|
| Intel LAN I225 Controller | √Enable, Disabled |
| Intel LAN I225 Controller | √Enable, Disabled |
| PCIE_WAKE(Wake On Lan)    | √Enable, Disabled |
| Launch UEFI PXE ROM       | Enable, √Disabled |

## Graphic Configuration


### Configuration of Graphic



| Graphic Configuration |                                                                                       |
|-----------------------|---------------------------------------------------------------------------------------|
| Primary Display       | vAuto, IGFX, PEG, PCI, SG                                                             |
| Internal Graphics     | vAuto, Disabled, Enabled                                                              |
| DVMT Pre-Allocated    | 32M, 64M, 4M, 8M, 12M, 16M, 20M, 24M, 28M, 32M/F7, 36M, 40M, 44M, 48M, 52M, 56M, v60M |
| DVMT Total Gfx Mem    | v256M, 128M, MAX                                                                      |

## PCI/ PCIE Configuration

### Configuration of PCI/ PCIE



| PCI Express Root Part 1 |                                 |
|-------------------------|---------------------------------|
| PCI Express Root Port 1 | vEnable, Disabled               |
| ASPM                    | vDisabled, Auto, L0sL1, L1, L0s |
| PCIe Speed              | vAuto, Gen1, Gen2, Gen3         |
| PCI Express Root Part 2 |                                 |
| PCI Express Root Port 2 | vEnable, Disabled               |
| ASPM                    | vDisabled, Auto, L0sL1, L1, L0s |
| PCIe Speed              | vAuto, Gen1, Gen2, Gen3         |
| PCI Express Root Part 3 |                                 |
| PCI Express Root Port 3 | vEnable, Disabled               |
| ASPM                    | vDisabled, Auto, L0sL1, L1, L0s |
| PCIe Speed              | vAuto, Gen1, Gen2, Gen3         |
| PCI Express Root Part 5 |                                 |
| PCI Express Root Port 5 | vEnable, Disabled               |
| ASPM                    | vDisabled, Auto, L0sL1, L1, L0s |
| PCIe Speed              | vAuto, Gen1, Gen2, Gen3         |

Power Control Configuration

Configuration

Aptio Setup - AMI

Power Control Configuration

Enable Hibernation

ACPI Sleep State

Restore AC Power Loss

Wake System from S5 via RTC

[Enabled]

[S3 (Suspend to RAM)]

[Power Off]

[Disabled]

Enables or Disables System ability to Hibernates (OS/S4 Sleep State). This option may not be effective with some operating systems.

→: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

F8: PCI List

F12: Capture Screen

ESC: Exit

Version 2.22.1284 Copyright (C) 2023 AMI

| Power Control Configuration |                                       |
|-----------------------------|---------------------------------------|
| Enable Hibernation          | √Enable, Disabled                     |
| ACPI Sleep State            | Suspend Disabled, √S3(Suspend to RAM) |
| Restore AC Power Loss       | Power On, √Power off, Last State      |
| RTC Wakeup                  | Enable, √Disabled                     |

## TPM Configuration

### Configuration of TPM



| TPM Configuration              |                       |
|--------------------------------|-----------------------|
| Security Device Support        | √Enable, Disabled     |
| SHA256 PCR Bank                | √Enable, Disabled     |
| Pending operation              | √None, TPM Clear      |
| Platform Hierarchy             | √Enable, Disabled     |
| Storage Hierarchy              | √Enable, Disabled     |
| Endorsement Hierarchy          | √Enable, Disabled     |
| TPM2.0 UEFI Spec Version       | √TCG_2, TCG_1.2       |
| Physical Presence Spec Version | √1.3, 1.2             |
| Device Select                  | √Auto, TPM1.2, TPM2.0 |

## Super IO Configuration


### Configure Super IO Parameters



| Super IO Configuration      |                   |
|-----------------------------|-------------------|
| Watch Dog Timer             | √Disable, Enable  |
| Serial Port 1 Configuration |                   |
| Serial Port                 | √Enable, Disabled |
| Serial Port 2 Configuration |                   |
| Serial Port                 | √Enable, Disabled |


## USB Configuration

### Configure USB Parameters



| SoC USB Configuration           |                                              |
|---------------------------------|----------------------------------------------|
| USB SS Physical Connector #0    | √Enable, Disabled                            |
| USB SS Physical Connector #1    | √Enable, Disabled                            |
| USB SS Physical Connector #2    | √Enable, Disabled                            |
| USB SS Physical Connector #3    | √Enable, Disabled                            |
| USB HS Physical Connector #0    | √Enable, Disabled                            |
| USB HS Physical Connector #1    | √Enable, Disabled                            |
| USB HS Physical Connector #2    | √Enable, Disabled                            |
| USB HS Physical Connector #3    | √Enable, Disabled                            |
| USB HS Physical Connector #4    | √Enable, Disabled                            |
| USB HS Physical Connector #5    | √Enable, Disabled                            |
| USB HS Physical Connector #6    | √Enable, Disabled                            |
| USB HS Physical Connector #7    | √Enable, Disabled                            |
| USB HS Physical Connector #8    | √Enable, Disabled                            |
| USB HS Physical Connector #9    | √Enable, Disabled                            |
| XHCI Hand-off                   | √Enable, Disabled                            |
| USB Mass Storage Driver Support | √Enable, Disabled                            |
| Mass Storage Devices            |                                              |
| Mass Storage Devices            | √Auto, Floppy, Forced FDD, Hard Disk, CD-ROM |

● 3.2.3 H/W Monitor  
Monitor hardware status



● 3.2.4 Security


This section lets you set security passwords to control access to the system at boot time and/or when entering the BIOS setup program.



| Password Description |                  |
|----------------------|------------------|
| Password Check Mode  | √Setup, Power on |

### ● 3.2.5 Boot


In this section, it will display the available devices on your system for you to configure the boot settings and the boot priority.



| Boot Configuration          |                                                                      |
|-----------------------------|----------------------------------------------------------------------|
| Setup Prompt Timeout        | 1                                                                    |
| Bootup NumLock State        | √On, Off                                                             |
| Full Screen Logo            | Enable, √Disabled                                                    |
| Fast Boot                   | Enable, √Disabled                                                    |
| FIXED BOOT ORDER Priorities |                                                                      |
| Boot Option #1              | USB Device, √Hard Disk, CD/DVD, Network, NVMe, SD, UEFI AP, Disabled |
| Boot Option #2              | USB Device, Hard Disk, CD/DVD, Network, √NVMe, SD, UEFI AP, Disabled |
| Boot Option #3              | USB Device, Hard Disk, √CD/DVD, Network, NVMe, SD, UEFI AP, Disabled |
| Boot Option #4              | USB Device, Hard Disk, CD/DVD, Network, NVMe, √SD, UEFI AP, Disabled |
| Boot Option #5              | √USB Device, Hard Disk, CD/DVD, Network, NVMe, SD, UEFI AP, Disabled |
| Boot Option #6              | USB Device, Hard Disk, CD/DVD, √Network, NVMe, SD, UEFI AP, Disabled |

|                             |                                                                       |
|-----------------------------|-----------------------------------------------------------------------|
| <b>Boot Option #7</b>       | USB Device, vHard Disk, CD/DVD, Network, NVMe, SD, vUEFI AP, Disabled |
| <b>Mass Storage Devices</b> |                                                                       |
| <b>Mass Storage Devices</b> | vAuto, Floppy, Forced FDD, Hard Disk, CD-ROM                          |

### ● 3.2.6 Exit



| <b>EXIT</b>                     |                                                                                       |
|---------------------------------|---------------------------------------------------------------------------------------|
| <b>Save Changes and Exit</b>    | Exit system setup after saving the changes. F4 key can be used for this operation.    |
| <b>Discard Changes and Exit</b> | Exit system setup without saving any changes. Esc key can be used for this operation. |

## **Chapter 4 Important Instructions**

This chapter includes instructions which must be carefully followed when the embedded system is used.

### **4.1 Note on the Warranty**

Due to their limited service life, parts which, by their nature, are especially subject to wear are not included in the guarantee beyond the legal stipulations.

### **4.2 Exclusion of Accident Liability Obligation**

Portwell, Inc. shall be exempt from the statutory accident liability obligation if users fail to abide by the safety instructions.

### **4.3 Liability Limitations / Exemption from the Warranty Obligation**

In the event of damage to the system unit caused by failure to abide by the hints in this manual and on the unit (especially the safety instructions), Portwell, Inc. shall not be required to respect the warranty even during the warranty period and shall be free from the statutory accident liability obligation.

### **4.4 Declaration of Conformity**

#### **EMC**

CE/FCC Class B

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference that may cause undesired operation.