




# LYNX-812C

SFF Embedded System

## User Manual

Version R 1.1

# Copyright

The documentation and the software included with this product are copyrighted 2024 by Portwell. All rights are reserved. Portwell reserves the right to make improvements to the products described in this manual at any time without notice. No part of this manual may be re-produced, copied, translated, or transmitted in any form or by any means without the prior written permission of Portwell. The information provided in this manual is intended to be accurate and reliable. However, Portwell assumes no responsibility for its use, nor for any infringements of the rights of third parties that may result from its use.

## Revision History

|       |                                             |
|-------|---------------------------------------------|
| R 1.0 | Initial Release Rev. 1.0                    |
| R 1.1 | Revise photos & add VESA mount installation |
|       |                                             |
|       |                                             |

# Table of Contents

|                                                          |    |
|----------------------------------------------------------|----|
| CHAPTER 1 PRODUCT OVERVIEW .....                         | 5  |
| 1.1 INSTRUCTION .....                                    | 6  |
| 1.2 PRODUCT SPECIFICATION .....                          | 7  |
| 1.3 DIMENSION .....                                      | 9  |
| CHAPTER 2 SYSTEM OVERVIEW .....                          | 10 |
| 2.1 I/O VIEW .....                                       | 11 |
| 2.2 JUMPER SETTING OF MAIN BOARD .....                   | 12 |
| 2.3 JUMPER SETTING OF EXTENSION BOARD .....              | 18 |
| CHAPTER 3 SYSTEM INSTALLATION .....                      | 23 |
| 3.1 OPEN THE SYSTEM .....                                | 24 |
| 3.2 M.2 2242 M key SATA SSD INSTALLATION .....           | 25 |
| 3.3 M.2 2230 E Key Wi-Fi MODULE INSTALLATION .....       | 27 |
| 3.4 Wi-Fi ANTENNA AND SMA BULKHEAD JACK INSTALLATION ... | 29 |
| 3.5 WALL MOUNT INSTALLATION .....                        | 31 |
| 3.6 DIN RAIL INSTALLATION .....                          | 31 |
| 3.7 VESA MOUNT INSTALLATION .....                        | 32 |
| CHAPTER 4 BIOS SETUP ITEMS .....                         | 34 |

|                                                                          |    |
|--------------------------------------------------------------------------|----|
| CHAPTER 5 IMPORTANT INSTRUCTION .....                                    | 72 |
| 5.1 NOTE ON THE WARRANTY.....                                            | 73 |
| 5.2 EXCUSION OF ACCIDENT LIABILITY OBLIGATION.....                       | 73 |
| 5.3 LIABILITY LIMITATIONS/EXEMPTION FROM THE WARRANTY<br>OBLIGATION..... | 73 |
| 5.4 DECLARATION OF CONFORMITY.....                                       | 73 |
| CHAPTER 6 PORTWELL SOFTWARE SERVICE.....                                 | 75 |
| 6.1 PET TOOL .....                                                       | 76 |

# Chapter 1

## Product Overview

- 1.1 Instruction
- 1.2 Product Specification
- 1.3 Dimension

## 1.1 Introduction

The LYNX-812C is a compact and reliable embedded computer, purpose-built for demanding industrial applications such as edge computing and gateway solutions. Based on the foundation of the LYNX-8110, the LYNX-812C is further enhanced with three additional 2.5GbE LAN ports through modular I/O expansion, enabling flexible network connectivity for data-intensive environments. Powered by the Intel® Atom® x7000RE series processor (x7433RE), the system delivers efficient computing performance while maintaining low power consumption, making it well-suited for a wide range of industrial and IoT deployments.

Designed for stability and durability, the LYNX-812C supports operation within a wide temperature range from -40° C to 70° C and adopts a fan-less architecture to minimize failure risks, ensuring long-term reliability even in harsh conditions. The wide range 12V to 30V DC input further enhances power flexibility, while the robust mechanical design provides resistance to vibration and shock for mission-critical applications.

In terms of connectivity and expansion, the system integrates versatile I/O interfaces including HDMI®, USB 3.2, USB Type-C with DisplayPort support, and five 2.5GbE LAN ports to meet diverse industrial networking requirements. Storage is supported through an onboard M.2 M key 2242 socket for SATA SSD, while the M.2 E key socket allows the installation of Wi-Fi modules. In addition, onboard LPDDR5 memory provides high-efficiency data access, and the inclusion of onboard eMMC and TPM ensures data integrity and security.

With its modular architecture, compact form factor, and support for both wall-mount and DIN rail installation, the LYNX-812C offers deployment versatility and seamless integration into various industrial environments. These features make it an ideal platform for vertical markets requiring multi-LAN connectivity, secure data handling, and reliable performance under extreme operating conditions.

## 1.2 Product Specification

| Model name                 | LYNX-812C                                                                                                               |
|----------------------------|-------------------------------------------------------------------------------------------------------------------------|
| General                    |                                                                                                                         |
| CPU                        | Intel® Amston Lake X7433RE, 4 cores, TDP 9W                                                                             |
| System Memory              | LPDDR5 4800 MT/s Non-ECC Memory chips up to 32GB (default: 8GB)                                                         |
| Storage                    | 1x M.2 M key 2242 socket (For SATA SSD)<br>Onboard eMMC up to 256GB (default:128GB)                                     |
| Power Input                | DC 12V~30V                                                                                                              |
| Operating System           | Windows 10/Windows 11/Linux                                                                                             |
| TPM                        | TPM2.0                                                                                                                  |
| Expansion                  | 1x M.2 E Key 2230 socket (For M.2 WiFi module)                                                                          |
| I/O Interface              |                                                                                                                         |
| Power Connector            | 1x 2-Pin Terminal Block Connector                                                                                       |
| Ethernet                   | 5x Intel® I226IT 2.5GbE LAN                                                                                             |
| USB                        | 2x USB 3.2 Gen2 (10Gbps)<br>1x USB Type C (DisplayPort/USB 10Gbps support)                                              |
| Display                    | 1x HDMI® 1.4a port<br>1x USB type C with DP ALT mode                                                                    |
| Certificate                |                                                                                                                         |
| Certificate                | CE (EN 55032; EN 55024/ EN 55035)<br>CE (EN 61000-6-4; EN 61000-6-2)<br>FCC (Part 15 Subpart Class A)<br>LVD (EN 62368) |
| Environmental & Mechanical |                                                                                                                         |
| Storage Temp.              | -40° C ~ 85 ° C                                                                                                         |
| Operating Temp.            | -40° C ~ 70° C                                                                                                          |
| Permissible Humidity       | 40° C, 95%RH, non-condensing                                                                                            |
| Operation Vibration        | 5Grms/10~500Hz, IEC 60068-2-6                                                                                           |
| Operation Shock            | 50G, 11msec, IEC 60068-2-27                                                                                             |

|                      |                               |
|----------------------|-------------------------------|
| Degree of Protection | IP40                          |
| Dimension            | 120mm(W) x 76mm(H) x 120mm(D) |

## 1.3 Dimension



Figure 1: LYNX-812C Mechanical Dimension

# Chapter 2

## System Overview

- 2.1 I/O View
- 2.2 Jumper Setting of Main Board
- 2.3 Jumper Setting of Extension Board

## 2.1 I/O View




Figure 2: LYNX-812C I/O View

| NO. | Description                                                                                             |
|-----|---------------------------------------------------------------------------------------------------------|
| 1   | 1x HDMI® 1.4a port                                                                                      |
| 2   | 2x USB 3.2 Gen2 (10Gbps) Ports                                                                          |
| 3   | 1x USB Type C (DisplayPort/USB 10Gbps support) Port                                                     |
| 4   | 2x Intel® I226IT 2.5GbE RJ45 Ports                                                                      |
| 5   | LED Indicators<br>The Green LED on the top: System power<br>The Red LED at the bottom: Storage Activity |
| 6   | 1x 2-Pin Terminal Block Connector                                                                       |
| 7   | 3x Intel® I226IT 2.5GbE RJ45 Ports                                                                      |
| 8&9 | SMA connectors for Wi-Fi / LTE module (Optional)                                                        |

## 2.2 Jumper Setting of Main Board

This chapter indicates jumpers' headers and connectors' locations. Users may find useful information related to hardware settings in this chapter.

### Drawing Overview




Figure 3: Component Side




Figure 4: Solder Side


### Jumper Setting List

| Location | Function             |
|----------|----------------------|
| JP1      | AT/ATX mode          |
| JP2      | Reserve for EC SMBus |
| JP3      | Clear CMOS setting   |

### JP1 AT/ATX Mode (Pitch 2.0mm)

| PCB Footprint                                                                       | Jumper Setting | Function Description |
|-------------------------------------------------------------------------------------|----------------|----------------------|
|  | 1-2            | ★AT Mode             |
|                                                                                     | 2-3            | Reserve              |

### JP2 Reserve for EC SMBus (EC SMBus (Pitch 2.0mm):Reserve)

| PCB Footprint                                                                     | Jumper Setting | Function Description |
|-----------------------------------------------------------------------------------|----------------|----------------------|
|  | 1              | 3.3V                 |
|                                                                                   | 2              | CLK                  |
|                                                                                   | 3              | DATA                 |
|                                                                                   | 4              | GND                  |

### JP3 CMOS Setup(Pitch 2.0mm)


| PCB Footprint                                                                     | Jumper Setting | Function Description |
|-----------------------------------------------------------------------------------|----------------|----------------------|
|  | 1-2            | Clear CMOS           |
|                                                                                   | 2-3            | Clear ME RTC         |

NOTES: Default (Floating)


### Connector Function List

| Location | Function                     |
|----------|------------------------------|
| J1       | Battery Connector            |
| J2       | HDMI Connector               |
| J3       | RJ45 Connector               |
| J4       | RJ45 Connector               |
| J5       | USB2.0/3.0 Connector         |
| J6       | DP ALT mode Type C Connector |
| J7       | M.2 Key E Wifi Connector     |
| J8       | DC Power Connector           |
| J28      | M.2 Key M SATA Connector     |


### J1: Battery Connector

| PCB Footprint                                                                       | Pin No. | Signal Description |
|-------------------------------------------------------------------------------------|---------|--------------------|
|  | 1       | BAT3V              |
|                                                                                     | 2       | GND                |


### J2: HDMI Connector

| PCB Footprint                                                                     | Pin No. | Signal Description | Pin No. | Signal Description |
|-----------------------------------------------------------------------------------|---------|--------------------|---------|--------------------|
|  | 1       | D2+                | 2       | D2 Shield          |
|                                                                                   | 3       | D2-                | 4       | D1+                |
|                                                                                   | 5       | D1 Shield          | 6       | D1-                |
|                                                                                   | 7       | D0+                | 8       | D0 Shield          |
|                                                                                   | 9       | D0-                | 10      | CLK+               |
|                                                                                   | 11      | CLK Shield         | 12      | CLK-               |
|                                                                                   | 13      | CEC                | 14      | HEC Data/Reserve   |
|                                                                                   | 15      | SCL                | 16      | SDA                |
|                                                                                   | 17      | DDC/CEC/HEC GND    | 18      | 5V                 |
|                                                                                   | 19      | HPD                |         |                    |


#### J3/J4: RJ45 Connector

| PCB Footprint                                                                       | Pin No. | Signal Description | Pin No. | Signal Description |
|-------------------------------------------------------------------------------------|---------|--------------------|---------|--------------------|
|  | 1       | TRxP0              | 2       | TRxN0              |
|                                                                                     | 3       | TRxP1              | 4       | TRxP2              |
|                                                                                     | 5       | TRxN2              | 6       | TRxN1              |
|                                                                                     | 7       | TRxP3              | 8       | TRxN3              |


#### J5: USB2.0/3.0 Connector

| PCB Footprint                                                                     | Pin No. | Signal Description | Pin No. | Signal Description |
|-----------------------------------------------------------------------------------|---------|--------------------|---------|--------------------|
|  | A1      | 5V                 | B1      | GND                |
|                                                                                   | A2      | D1-                | B2      | D0-                |
|                                                                                   | A3      | D1+                | B3      | D0+                |
|                                                                                   | A4      | GND                | B4      | GND                |
|                                                                                   | A5      | SSRX1-             | B5      | SSRX0-             |
|                                                                                   | A6      | SSRX1+             | B6      | SSRX0+             |
|                                                                                   | A7      | GND                | B7      | GND                |
|                                                                                   | A8      | SSTX1-             | B8      | SSRTX0-            |
|                                                                                   | A9      | SSTX1+             | B9      | SSRTX0+            |

J6: DP ALT Mode Type C Connector


| PCB Footprint                                                                       | Pin No. | Signal Description | Pin No. | Signal Description |
|-------------------------------------------------------------------------------------|---------|--------------------|---------|--------------------|
|  | A1      | GND                | B12     | GND                |
|                                                                                     | A2      | SSTXp1(TX1+)       | B11     | SSRXp1(RX1+)       |
|                                                                                     | A3      | SSTXn1(TX1-)       | B10     | SSRXn1(RX1-)       |
|                                                                                     | A4      | Vbus               | B9      | Vbus               |
|                                                                                     | A5      | CC1                | B8      | SBU2               |
|                                                                                     | A6      | D+                 | B7      | D-                 |
|                                                                                     | A7      | D-                 | B6      | D+                 |
|                                                                                     | A8      | SBU1               | B5      | CC2                |
|                                                                                     | A9      | Vbus               | B4      | Vbus               |
|                                                                                     | A10     | SSRXn2(RX2-)       | B3      | SSRTn2(TX2-)       |
|                                                                                     | A11     | SSRXp2(RX2+)       | B2      | SSRTp2(TX2+)       |
|                                                                                     | A12     | GND                | B1      | GND                |

J7: M.2 Key E WiFi Connector




**Follow PCI Express M.2 Specification Ver5.1**

J8: DC Power input Connector

| PCB Footprint                                                                     | Jumper Setting | Function Description |
|-----------------------------------------------------------------------------------|----------------|----------------------|
|  | 1              | GND                  |
|                                                                                   | 2              | +12V                 |

J28: M.2(SATA interface TYPE:2242) Connector



**Follow PCI Express M.2 Specification Ver5.1**

## 2.3 Jumper Setting of Extension

### Board

This chapter indicates jumpers' headers and connectors' locations of extension board. Users may find useful information related to hardware settings in this chapter.

#### Drawing Overview





Figure 5: Component Side

## Jumper Setting List


| Location | Function             |
|----------|----------------------|
| J1       | LAN1                 |
| J2       | LAN2                 |
| J3       | LAN3                 |
| J4       | GPIO Pin Header      |
| J5       | USB2.0 Pin Header    |
| J6       | PClex8 Golden Finger |

J1、J2、J3: RJ45: LAN




| PIN No. | Signal Description | PIN No. | Signal Description |
|---------|--------------------|---------|--------------------|
| 1       | TRxP0              | 2       | TRxN0              |
| 3       | TRxP1              | 4       | TRxP2              |
| 5       | TRxN2              | 6       | TRxN1              |
| 7       | TRxP3              | 8       | TRxN3              |

J4: Box Header: GPIO




| PIN No. | Signal Description | PIN No. | Signal Description |
|---------|--------------------|---------|--------------------|
| 1       | GP00               | 2       | GPI0               |
| 3       | GP01               | 4       | GPI1               |
| 5       | GP02               | 6       | GPI2               |
| 7       | GP03               | 8       | GPI3               |
| 9       | GND                | 10      | 3.3V               |

J5: Wafer: USB2.0



| PIN No. | Signal Description | PIN No. | Signal Description |
|---------|--------------------|---------|--------------------|
| 1       | 5V                 | 2       | USB_D              |
| 3       | USB_D+             | 4       | GND                |

J6: PCIe8 Golden Finger



| PIN No. | Signal Description | PIN No. | Signal Description |
|---------|--------------------|---------|--------------------|
| A1      | V3P3A              | B1      | V3P3S              |
| A2      | V3P3A              | B2      | V3P3S              |
| A3      | V3P3A              | B3      | V3P3S              |
| A4      | GND                | B4      | GND                |
| A5      | GPI0               | B5      | GP00               |
| A6      | GPI1               | B6      | GP01               |

| PIN No. | Signal Description | PIN No. | Signal Description |
|---------|--------------------|---------|--------------------|
| A7      | GPI2               | B7      | GPO2               |
| A8      | GPI3               | B8      | GPO3               |
| A9      | V12P0A             | B9      | V5P0A              |
| A10     | V12P0A             | B10     | V5P0A              |
| A11     | PCIE_RST#          | B11     | PCIE_WAKE#         |
| A12     | NC                 | B12     | GND                |
| A13     | PCIE_CLKREQ4_N     | B13     | PCIECLK_DIFF_N4    |
| A14     | PCIE_CLKREQ3_N     | B14     | PCIECLK_DIFF_P4    |
| A15     | NC                 | B15     | GND                |
| A16     | NC                 | B16     | PCIECLK_DIFF_N3    |
| A17     | KBC_SLP_S3#        | B17     | PCIECLK_DIFF_P3    |
| A18     | GND                | B18     | GND                |
| A19     | PCIE_TXN12_C       | B19     | PWRBTN#_D          |
| A20     | PCIE_TXP12_C       | B20     | GND                |
| A21     | GND                | B21     | PCIE_RXN12         |
| A22     | GND                | B22     | PCIE_RXP12         |
| A23     | PCIE_TXN4_C        | B23     | GND                |
| A24     | PCIE_TXP4_C        | B24     | GND                |
| A25     | GND                | B25     | PCIE_RXN4          |
| A26     | GND                | B26     | PCIE_RXP4          |
| A27     | PCIE_TXN3_C        | B27     | GND                |
| A28     | PCIE_TXP3_C        | B28     | GND                |
| A29     | GND                | B29     | PCIE_RXN3          |
| A30     | USB_PN3            | B30     | PCIE_RXP3          |
| A31     | USB_PP3            | B31     | GND                |
| A32     | USB2_OC3           | B32     | LAD0               |
| A33     | USB_PN2            | B33     | LAD1               |
| A34     | USB_PP2            | B34     | LAD2               |
| A35     | NC                 | B35     | LAD3               |
| A36     | HDA_BCLK           | B36     | LRESET#            |
| A37     | HDA_SYNC           | B37     | PCICLK             |

| PIN No. | Signal Description | PIN No. | Signal Description |
|---------|--------------------|---------|--------------------|
| A38     | HDA_SDO            | B38     | LFRAME#            |
| A39     | HDA_SDI0           | B39     | SERIRQ             |
| A40     | HDA_RST            | B40     | GPIO1_R / Reserved |
| A41     | SP339_COM1_Mode0   | B41     | GPIO2_R / Reserved |
| A42     | SP339_COM1_Mode1   | B42     | GPIO3_R / Reserved |
| A43     | SP339_COM1_Mode2   | B43     | GPIO4_R / Reserved |
| A44     | NC                 | B44     | SMB_CLK            |
| A45     | SP339_COM2_Mode0   | B45     | SMB_DAT            |
| A46     | SP339_COM2_Mode1   | B46     | SMB_ALT#           |
| A47     | SP339_COM2_Mode2   | B47     | NC                 |
| A48     | NC                 | B48     | RSTBTN#            |
| A49     | NC                 | B49     | BUF_PLTRST#        |




# Chapter 3

## System Overview

- 3.1 Open The Chassis
- 3.2 M.2 2242 M Key SATA SSD Installation
- 3.3 M.2 2230 E Key Wi-Fi Module Installation
- 3.4 Wi-Fi Antenna and SMA Bulkhead Jack Installation
- 3.5 Wall Mount Installation
- 3.6 Din Rail Installation
- 3.7 VESA mount Installation

## 3.1 Open the System



Before disassembly, ensure the system is powered off and all power sources and signal cables are disconnected.

|                                                                                     |                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <p>There are 11 screws on the bottom cover of the LYNX-812C. Loosen the 8 marked screws (M3 × 4L).</p>                                                                                            |
|  | <p>Remove the red-marked 5 screws (M3 × 4L). Gently pull the rear cover outward; the riser card attached to the cover will come out together with it. A slight amount of force may be needed.</p> |
|  | <p>After removing the bottom cover and rear cover assembly, the internal structure will appear as picture showed.</p>                                                                             |

## 3.2 M.2 2242 M Key SATA SSD

### Installation

The system is equipped with one M.2 M Key 2242 socket for a SATA SSD. Follow the instructions below to install the SSD.



Loosen the 4 red-marked screws securing the aluminum plate, then remove the plate.



Align the M.2 card with the module slot, insert it at a slight angle, and ensure the connector is fully seated.




Press the M.2 card down to a horizontal position and secure it with the bundled screw (M3 x 6L).


## 3.3 M.2 2230 E Key Wi-Fi Module

### Installation


The system is equipped with one M.2 E Key 2230 socket for Wi-Fi card. Follow the instructions below to install it.



Loosen the 4 red-marked screws securing the aluminum plate, then remove the plate.



Align the M.2 card with the module slot, insert it at a slight angle, and ensure the connector is fully seated.



Press the M.2 card down to a horizontal position and secure it with the bundled screw (M3 x 6L).


## 3.4 Wi-Fi Antenna and SMA

### Bulkhead Jack Installation


LYNX-812C has 6 antenna holes to support Wi-Fi Antenna.

Follow the instructions below for installation.

|                                                                                     |                                                                                                                                                                                                                                                                                                                                       |
|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | <p>If Wi-Fi module is purchased, the accessory box will include the following items</p> <ul style="list-style-type: none"> <li>1 × Wi-Fi M.2 card</li> <li>2 × serrated washer</li> <li>2 × hex nut</li> <li>2 × SMA cables (SMA female to IPEX MHF4L)</li> <li>2 × external Wi-Fi antennas</li> </ul>                                |
|  | <ol style="list-style-type: none"> <li>1. Remove the antenna hole plug from the front panel. Alternatively, use an appropriate screwdriver to push out the pre-punched antenna hole from the outside to the inside.</li> <li>2. Insert the SMA cable through the antenna hole so that the threaded part protrudes outside.</li> </ol> |

|                                                                                     |                                                                                                                                                                                                                                                                     |
|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <p>(Take antenna holes on the front panel as an example)</p> <ol style="list-style-type: none"> <li>1. On the outside of the chassis, place the serrated washer over the threaded connector.</li> <li>2. Secure the connector by tightening the hex nut.</li> </ol> |
|    | <p>Inside the chassis, align each MHF4 connector on the antenna cable with the corresponding port on the Wi-Fi card.</p>                                                                                                                                            |
|  | <p>Press straight down until a click is felt or heard.</p>                                                                                                                                                                                                          |
|  | <ol style="list-style-type: none"> <li>1. Screw each external Wi-Fi antenna onto the SMA connector on the chassis.</li> <li>2. Adjust the antennas to the desired position for optimal signal reception.</li> </ol>                                                 |


## 3.5 Wall mount Installation


|                                                                                   |                                                                                                                                                                                                            |
|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>Remove the pre-installed screws and align the wall mount brackets with the mounting holes on the bottom cover of the system. Secure the brackets to the system using the supplied screws (M3 × 6L).</p> |
|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## 3.6 Din Rail Installation

|                                                                                     |                                                                                                                                                                                                          |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>Remove the pre-installed screws on the rear panel of the system, then align the DIN rail brackets with the mounting holes. Secure the brackets to the system using the supplied screws (M3 × 6L).</p> |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## 3.7 VESA mount Installation

|                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <p>The VESA mount kit contained:</p> <ol style="list-style-type: none"> <li>1. VESA Mounting Plate (1 pc): A black metal plate featuring standard VESA mounting patterns.</li> <li>2. Device Mounting Brackets (2 pcs): Long brackets equipped with teardrop keyholes at the top for secure hanging.</li> <li>3. Screw Pack (Not shown in image): Typically includes M4 screws for monitor attachment and for securing the device.</li> </ol>              |
|   | <p>Remove the pre-installed screws and align the wall mount brackets with the mounting holes on the bottom cover of the system.</p>                                                                                                                                                                                                                                                                                                                        |
|  | <ol style="list-style-type: none"> <li>1. Mount the VESA Plate: First, secure the VESA mounting plate onto your target surface (e.g., the back of a monitor or a wall mount).</li> <li>2. Position the Brackets: Place the brackets onto the device (example showed I/O ports facing downward.)</li> <li>3. Secure the Screws: Insert and tighten the four screws (indicated by the yellow arrows) to firmly attach the brackets to the device.</li> </ol> |

|                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|    | <ol style="list-style-type: none"> <li>1. Align the Keyholes: Lift the LYNX-812B and align the teardrop keyholes on the brackets with the mounting studs (I-shaped pins) on the VESA plate.</li> <li>2. Slide to Lock: Insert the studs into the wider part of the keyholes, then gently slide the device downward until it is firmly locked into place.</li> </ol> <p><b>Final Check:</b> Ensure the device is secure and level before releasing your grip.</p>                                                |
|  | <ol style="list-style-type: none"> <li>1. Fasten the Security Screws: Install and tighten the two security screws at the bottom of the VESA plate to lock the mounting brackets in place.</li> <li>2. Prevent Detachment: This step ensures the device is firmly fixed to the VESA plate and prevents it from accidentally sliding out or being detached.</li> </ol> <p><b>Final Inspection:</b> Double-check that all screws (both the bracket-to-device and plate-to-bracket screws) are fully tightened.</p> |

# Chapter 4

## BIOS Setup Items

- 4.1 Entering Setup
- 4.2 Main
- 4.3 Configuration
- 4.4 Security
- 4.5 Boot
- 4.6 Save & Exit

LYNX-812C is equipped with the AMI BIOS stored in Flash ROM. These BIOS have a built-in Setup program that allows users to modify the basic system configuration easily. This type of information is stored in CMOS RAM so that it is retained during power-off periods. When system is turned on, LYNX-812C Series communicates with peripheral devices and checks its hardware resources against the configuration information stored in the CMOS memory. If any error is detected, or the CMOS parameters need to be initially defined, the diagnostic program will prompt the user to enter the SETUP program. Some errors are significant enough to abort the start up.

## 4.1 Entering Setup -- Launch System Setup

Power on the computer and the system will start POST (Power On Self Test) process. When the message below appears on the screen, press <Del> key will enter BIOS setup screen.


### **Press <Del> to enter SETUP**

If the message disappears before responding and still wish to enter Setup, please restart the system by turning it OFF and On or pressing the RESET button. It can be also restarted by pressing <Ctrl>, <Alt>, and <Delete> keys on keyboard simultaneously.

### Press <F1> to Run General Help or Resume

The BIOS setup program provides a General Help screen. The menu can be easily called up from any menu by pressing <F1>. The Help screen lists all the possible keys to use and the selections for the highlighted item.

Press <Esc> to exit the Help screen.



## 4.2 Main

Use this menu for basic system configurations, such as time, date etc.



| Feature     | Description                                                                                      | Options |
|-------------|--------------------------------------------------------------------------------------------------|---------|
| System Date | The date format is <Day>, <Month> <Date> <Year>.<br>Use [ + ] or [ - ] to configure system Date. |         |
| System Time | The time format is <Hour> <Minute> <Second>.<br>Use [ + ] or [ - ] to configure system Time.     |         |

## Detailed System Information

```

Main
Apollio Setup - AMI

FSP Information
FSP version          0C.02.89.40
RC version           0C.E0.89.40
Build Date
FSP Mode             Dispatch Mode

Board Information
Board Name            LSMC-M1013
Board ID              N/A
Fab ID                Default string
LAN PHY Revision      N/A

Processor Information
Name                  AlderLake ULX
Type                  Intel(R) Atom(TM) x7433RE
Speed                 1500 MHz
ID                    0xB06E0
Stepping              A0
Package               Not Implemented Yet
Number of Efficient-cores 4Core(s) / 4Thread(s)
Microcode Revision    15
GT Info                0x46D0
eDRAM Size            N/A

IGFX GOP Version      21.1.6
Memory RC Version     0.0.4.74
Total Memory          8192 MB
Memory Frequency      4800 MHz
MC 0 Ch 0 DIMM 0     Populated & Enabled
Size                  2048 MB (LPDDR5)
MC 0 Ch 1 DIMM 0     Populated & Enabled
Size                  2048 MB (LPDDR5)
MC 0 Ch 2 DIMM 0     Populated & Enabled


Version 2.22.1289 Copyright (C) 2025 AMI

```


|                                |                                         |
|--------------------------------|-----------------------------------------|
| Main                           |                                         |
| MC 0 Ch 1 DIMM 0<br>Size       | Populated & Enabled<br>2048 MB (LPDDR5) |
| MC 0 Ch 2 DIMM 0<br>Size       | Populated & Enabled<br>2048 MB (LPDDR5) |
| MC 0 Ch 3 DIMM 0<br>Size       | Populated & Enabled<br>2048 MB (LPDDR5) |
| MC 1 Ch 0 DIMM 0               | Not Populated / Disabled                |
| MC 1 Ch 1 DIMM 0               | Not Populated / Disabled                |
| MC 1 Ch 2 DIMM 0               | Not Populated / Disabled                |
| MC 1 Ch 3 DIMM 0               | Not Populated / Disabled                |
| PCH Information                |                                         |
| Name                           | PCH-N                                   |
| PCH SKU                        | N ASL IOT INDU SKU                      |
| Stepping                       | A0                                      |
| ChipsetInit Base Revision      | 2                                       |
| ChipsetInit OEM Revision       | 0                                       |
| Package                        | Not Implemented Yet                     |
| TXT Capability of Platform/PCH | Unsupported                             |
| Production Type                | Production                              |
| Dual Output Fast Read support  |                                         |
| Read ID/Status Clock Freq      | 50 MHz                                  |
| Write and Erase Clock Freq     | 50 MHz                                  |
| Fast Read Clock Freq           | 50 MHz                                  |
| Fast Read support              | Supported                               |
| Number of Components           | 1 Component                             |
| SPI Component 0 Density        | 32 MB                                   |
| eSPI Flash Sharing Mode        |                                         |
| EC PEFI Mode                   | G3                                      |
| ME FW Version                  | Legacy PEFI mode                        |
| ME Firmware SKU                | 16.50.10.1351                           |
| PMC FW Version                 | Consumer SKU                            |
|                                | 160.50.0.1009                           |

## 4.3 Configuration

Use this menu to set up the items of special enhanced features




### 4.3.1 CPU Configuration



| Feature                               | Description                                                                                                                                | Options                                                    |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------|
| Active Efficient-Cores                | Number of E-cores to enable in each processor package.<br>Note: Number of Cores and E-cores are looked at together                         | ★All, 3, 2, 1                                              |
| Boot performance mode                 | Select the performance state that the BIOS will set starting from reset vector                                                             | ★Max Non-Turbo Performance, Turbo Performance, Max Battery |
| Intel (VMX) Virtualization Technology | When enabled, a VMM can utilize the additional hardware capabilities provided by Vander pool Technology.                                   | Disabled, ★Enabled                                         |
| Intel (R) Speed Step (tm)             | Allows more than two frequency ranges to be supported.                                                                                     | Disabled, ★Enabled                                         |
| Intel (R) Speed Shift Technology      | Enable/Disable Intel® Speed Shift Technology support. Enabling will expose the CPPC v2 interface to allow for hardware-controlled P-states | Disabled, ★Enabled                                         |
| Turbo Mode                            | Enable/Disable processor Turbo Mode (requires EMTTM enabled too).<br>AUTO means enabled.                                                   | ★Disabled, Enabled                                         |

| Feature                     | Description                                                                                                   | Options            |
|-----------------------------|---------------------------------------------------------------------------------------------------------------|--------------------|
| C states                    | Enable/disable CPU Power Management. Allows CPU to go to C states when it's not 100% utilized.                | Disabled, ★Enabled |
| Enhanced C-states           | Enable/Disable C1E. When enabled, CPU will switch to minimum speed when all cores enter C-state               | Disabled, ★Enabled |
| C-State Auto Demotion       | Configure C-State Auto Demotion                                                                               | Disable, ★C1       |
| C-State Un-demotion         | Configure C-State Un-demotion                                                                                 | Disable, ★C1       |
| Package C-state Demotion    | Package C-State Demotion                                                                                      | Disabled, ★Enabled |
| Package C-state Un-demotion | Package C-State Un-demotion                                                                                   | Disabled, ★Enabled |
| C-State Pre-Wake            | Disable – Sets bit 30 of POWER_CTL MSR(0x1FC) to 1 to disable the C-state Pre-Wake                            | Disabled, ★Enabled |
| IO MWAIT Redirection        | When set, will map IO_read instructions sent to IO registers<br>PMG_IO_BASE_ADDRBASE+offset to MWAIT (offset) | ★Disabled, Enabled |


### 4.3.2 Chipset Configuration



| Feature                            | Description                                                                                        | Options                                    |
|------------------------------------|----------------------------------------------------------------------------------------------------|--------------------------------------------|
| LAN ByPass Control                 | LAN ByPass Control Enabled.                                                                        | ★Disabled, Enabled                         |
| LAN ByPass Control [Enabled.]      |                                                                                                    |                                            |
| LAN A ByPass Mode<br>- Next Boot   | Next Boot ByPass Mode Config                                                                       | ★Normal Mode,<br>Open Mode,<br>ByPass Mode |
| LAN A ByPass Mode<br>- Power Off   | Power Off ByPass Mode Config.                                                                      | ★Normal Mode,<br>Open Mode,<br>ByPass Mode |
| LAN A ByPass Mode<br>- WDT Trigger | WDT Trigger ByPass Mode Config.                                                                    | ★Normal Mode,<br>Open Mode,<br>ByPass Mode |
| LAN A ByPass Mode<br>- WDT TimOut  | WDT TimOut ByPass Mode Config.                                                                     | ★Normal Mode,<br>Open Mode,<br>ByPass Mode |
| VT-d                               | VT-d Capability                                                                                    | Disabled, ★Enabled                         |
| Above 4GB MMIO<br>BIOS assignment  | Enable/Disable above 4GB Memory<br>Mapped IO BIOS assignment<br>This is enabled automatically when | Disabled, ★Enabled                         |

| Feature              | Description                                                                                                                   | Options            |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------|--------------------|
| HD Audio             | Control Detection of the HD-Audio device.<br>Disabled = HDA unconditionally disabled<br>Enabled = HDA unconditionally enabled | ★Disabled, Enabled |
| Me FW Image Re-Flash | Enable/Disable Me FW Image Re-Flash function.                                                                                 | ★Disabled, Enabled |
| eMMC 5.1 Controller  | Enable or Disable SCS eMMC 5.1 Controller                                                                                     | Disabled, ★Enabled |


### 4.3.3 Graphics Configuration



| Feature            | Description                                                                                      | Options                                                                                             |
|--------------------|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| Primary Display    | Select which of IGFX Graphics device should be Primary Display or Select HG for Hybrid Gfx.      | ★Auto, IGFX                                                                                         |
| Internal Graphics  | Keep IGFX enable based on the setup options.                                                     | ★Auto, Disabled, Enabled                                                                            |
| DVMT Pre-Allocated | Select DVMT 5.0 Pre-Allocated (Fixed) Graphics Memory size used by the Internal Graphics Device. | 32M, 64M, 96M, 128M, 160M, 12M, 16M, 16M, 20M, 24M, 28M, 32M/F7, 36M, 40M, 44M, 48M, 52M, 56M, ★60M |

| Feature            | Description                                                                   | Options          |
|--------------------|-------------------------------------------------------------------------------|------------------|
| DVMT Total Gfx Mem | Select DVMT5.0 Total Graphic Memory size used by the Internal Graphics Device | ★256M, 128M, MAX |


#### 4.3.4 Power Control Configuration



| Feature              | Description                                                                                                                                     | Options                                   |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------|
| Enable Hibernation   | Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may not be effective with some operating systems.              | Disabled, ★<br>Enabled                    |
| ACPI Sleep State     | Select the highest ACPI sleep state the system will enter when the SUSPEND button is pressed.                                                   | ★S3 (Suspend to RAM), Suspend<br>Disabled |
| RTC Wakeup           | Enable or Disable System wake on alarm event.<br>[Enabled] system will wake on the<br>Hour:Min:Sec specified.<br>[Disabled] Turn off RTC wakeup | ★Disabled,<br>Enabled                     |
| RTC Wakeup [Enabled] |                                                                                                                                                 |                                           |


| Feature                 | Description                                                                                                 | Options     |
|-------------------------|-------------------------------------------------------------------------------------------------------------|-------------|
| Wake up day             | Select 0 for daily system wake up 1-31 for which day of the month that you would like the system to wake up | ★0          |
| Wake up Time (HH:mm:ss) | Use [Enter], [TAB] to select field, HH: 0-23 mm: 0-59 ss: 0-59                                              | ★[00:00:00] |

### 4.3.5 PCI/PCIE Configuration



| Feature                               | Description                           | Options            |
|---------------------------------------|---------------------------------------|--------------------|
| HSIO Combo Port Override              | ME config override enable or disable. | ★Disabled, Enabled |
| HSIO Combo Port Override [Enabled]    |                                       |                    |
| (J9) Extended IO PCIe 1/2 Bifurcation | Control PCH PCIe lane width.          | 2x1, ★1x2          |
| (J9) Extended IO 2 Type               | Control USB/PCIe combo port.          | USB, ★PCIe         |
| (J9) Extended IO 3 Type               | Control USB/PCIe combo port.          | USB, ★PCIe         |


### 4.3.6 LAN Configuration



| Feature                       | Description                                                                                       | Options            |
|-------------------------------|---------------------------------------------------------------------------------------------------|--------------------|
| PCIE_WAKE (Wake on Lan)       | Control PCIE Wake# pin for wake on Lan function.                                                  | Disabled, ★Enabled |
| Launch UEFI PXE ROM           | Enable/Disable UEFI Network Stack                                                                 | ★Disabled, Enabled |
| Launch UEFI PXE ROM (Enabled) |                                                                                                   |                    |
| IPv4 PXE Support              | Enable/Disable IPv4 PXE boot support. If disabled, IPv4 PXE boot support will not be available.   | Disabled, ★Enabled |
| IPv4 HTTP Support             | Enable/Disable IPv4 HTTP boot support. If disabled, IPv4 HTTP boot support will not be available. | Disabled, ★Enabled |
| IPv6 PXE Support              | Enable/Disable IPv6 PXE boot support. If disabled, IPv6 PXE boot support will not be available.   | Disabled, ★Enabled |
| IPv6 HTTP Support             | Enable/Disable IPv6 HTTP boot support. If disabled, IPv6 HTTP boot support will not be available. | Disabled, ★Enabled |


| Feature            | Description                                                                                                   | Options |
|--------------------|---------------------------------------------------------------------------------------------------------------|---------|
| PXE boot wait time | Wait time in seconds to press ESC key to abort the PXE boot. Use either +/- or numeric keys to set the value. | ★0      |
| Media detect count | Number of times the presence of media will be checked. Use either +/- or numeric keys to set the value.       | ★1      |

### 4.3.7 SATA Configuration



| Feature                 | Description                                                                  | Options                             |
|-------------------------|------------------------------------------------------------------------------|-------------------------------------|
| SATA Controller(s)      | Enable/Disable SATA Device                                                   | Disabled, ★Enabled                  |
| (J28) Serial ATA Port 0 |                                                                              |                                     |
| Port 0                  | Enabled or Disabled SATA Port                                                | Disabled, ★Enabled                  |
| SATA Device Type        | Identify the SATA port is connected to Solid State Drive or Hard Disk Drive. | ★Hard Disk Drive, Solid State Drive |

### 4.3.8 USB Configuration




| Feature                    | Description                                                                                                                                            | Options            |
|----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|
| (J6) Type-C Port #0        | Enabled/Disabled TCSS xHCI                                                                                                                             | Disabled, ★Enabled |
| USB 3.2 Port Configuration |                                                                                                                                                        |                    |
| (J5) USB3.2 #0             | Enable/Disable this USB Physical connector (Physical port). Once disabled, any USB devices plug into the connector will not be detected by BIOS or OS. | Disabled, ★Enabled |
| (J5) USB3.2 #1             | Enable/Disable this USB Physical connector (Physical port). Once disabled, any USB devices plug into the connector will not be detected by BIOS or OS. | Disabled, ★Enabled |

| Feature                         | Description                                                                                                                                                                                             | Options                                      |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------|
| USB 2.0 Port Configuration      |                                                                                                                                                                                                         |                                              |
| (J5) USB2.0 #0                  | Enable/Disable this USB Physical connector (Physical port). Once disabled, any USB devices plug into the connector will not be detected by BIOS or OS.                                                  | Disabled, ★Enabled                           |
| (J5) USB2.0 #1                  | Enable/Disable this USB Physical connector (Physical port). Once disabled, any USB devices plug into the connector will not be detected by BIOS or OS.                                                  | Disabled, ★Enabled                           |
| (J9) Extended USB2.0 Port 1     | Enable/Disable this USB Physical connector (Physical port). Once disabled, any USB devices plug into the connector will not be detected by BIOS or OS.                                                  | Disabled, ★Enabled                           |
| (J7) USB2.0 M.2 Key-E           | Enable/Disable this USB Physical connector (Physical port). Once disabled, any USB devices plug into the connector will not be detected by BIOS or OS.                                                  | Disabled, ★Enabled                           |
| XHCI Hand-off                   | This is a workaround for OSes without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver                                                                                 | Disabled, ★Enabled                           |
| USB Mass Storage Driver Support | Enable/Disable USB Mass Storage Driver Support                                                                                                                                                          | Disabled, ★Enabled                           |
| Mass storage Devices:           |                                                                                                                                                                                                         |                                              |
| Generic Flash Disk 8.07         | Mass storage device emulation type. 'AUTO' enumerates devices according to their media format. Optical drives are emulated as 'CDROM'; drives with no media will be emulated according to a drive type. | ★Auto, Floppy, Forced FDD, Hard Disk, CD-ROM |

### 4.3.9 TPM Configuration:


#### TPM 2.0 Device Found



| Feature                 | Description                                                                                                                                            | Options            |
|-------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|
| Security Device Support | Enables or Disables BIOS support for security devices. O.S. will not show Security Device. TCG EFI protocol and INT1A Interface will not be available. | Disabled, ★Enabled |
| SHA256 PCR Bank         | Enables or Disables SHA256 PCR Bank.                                                                                                                   | Disabled, ★Enabled |
| SHA384 PCR Bank         | Enables or Disables SHA384 PCR Bank.                                                                                                                   | ★Disabled Enabled, |
| Pending operation       | Schedule an Operation for the Security Device. Note: Your computer will reboot during restart in order to change State of Security Device.             | ★None, TPM Clear   |
| Platform Hierarchy      | Enables or Disables Platform Hierarchy.                                                                                                                | Disabled, ★Enabled |
| Storage Hierarchy       | Enables or Disables Storage Hierarchy.                                                                                                                 | Disabled, ★Enabled |
| Endorsement Hierarchy   | Enables or Disables Endorsement Hierarchy.                                                                                                             | Disabled, ★Enabled |


| Feature                        | Description                                                                                                                                                                                                          | Options                    |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|
| TPM2.0 UEFI Spec Version       | Select the TCG2 Spec Version Support.<br>TCG_1_2: the Compatible mode for Win8/Win10.<br>TCG_2: Support new TCG2 protocol and event format for Win10 or later.                                                       | TCG_1_2,<br>★TCG_2         |
| Physical Presence Spec Version | Select to Tell O.S. to Support PPI Spec Version 1.2 or 1.3. Not some HCK tests might not support 1.3.                                                                                                                | 1.2, ★1.3                  |
| Device Select                  | TPM 1.2 will restrict support to TPM 1.2 devices, TPM 2.0 will restrict support to TPM 2.0 devices, Auto will support both with the default set to TPM 2.0 devices if not found, TPM 1.2 devices will be enumerated. | ★Auto, TPM 1.2,<br>TPM 2.0 |

#### 4.3.10 Super IO Configuration



| Feature                   | Description                           | Options            |
|---------------------------|---------------------------------------|--------------------|
| Watch Dog Timer           | Enable/Disable Watch Dog Timer        | ★Disabled, Enabled |
| Watch Dog Timer [Enabled] |                                       |                    |
| Timer Unit                | Select Timer count unit of WDT        | ★Second, Minute    |
| Timer value               | Set WDT Timer value seconds / minutes | ★20                |

### 4.3.11 HW Monitor



### 4.3.12 Serial Port Console Redirection


| Configuration                            |  | Aptio Setup - AMI                                                                                                                                                                                                    |  |
|------------------------------------------|--|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| Serial Port Console Redirection          |  |                                                                                                                                                                                                                      |  |
|                                          |  | ++: Select Screen<br>↑: Select Item<br>Enter: Select<br>+/-: Change Opt.<br>F1: General Help<br>F2: Previous Values<br>F3: Optimized Defaults<br>F4: Save & Exit<br>F8: PCI List<br>F12: Capture Screen<br>ESC: Exit |  |
| Version 2.22.1289 Copyright (C) 2025 AMI |  |                                                                                                                                                                                                                      |  |

### 4.3.13 EC Firmware Update



| Configuration                            |                  | Aptio Setup - AMI                                                                                                                                                                                                    |  |
|------------------------------------------|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| EC Firmware Update                       |                  | Select ROM image                                                                                                                                                                                                     |  |
| EC Model Name                            | SMC-013          |                                                                                                                                                                                                                      |  |
| EC Version & Build Date                  | 0.5 (07/01/2025) |                                                                                                                                                                                                                      |  |
| ▶ Select File                            |                  |                                                                                                                                                                                                                      |  |
| Select File Name                         | N/A              |                                                                                                                                                                                                                      |  |
| ▶ Update                                 |                  |                                                                                                                                                                                                                      |  |
|                                          |                  | ++: Select Screen<br>↑: Select Item<br>Enter: Select<br>+/-: Change Opt.<br>F1: General Help<br>F2: Previous Values<br>F3: Optimized Defaults<br>F4: Save & Exit<br>F8: PCI List<br>F12: Capture Screen<br>ESC: Exit |  |
| Version 2.22.1289 Copyright (C) 2025 AMI |                  |                                                                                                                                                                                                                      |  |

| Feature     | Description                                   | Options |
|-------------|-----------------------------------------------|---------|
| Select File | Select BIOS BIN file in (USB) drive to update |         |
| Update      | Start updating ROM image                      |         |

## Select file




## Update EC



### 4.3.14 Tls Auth Configuration


#### Server CA Configuration

Press <Enter> to configure Server CA.




## Enroll Cert

Press <Enter> to enroll cert




## Enroll Cert Using File

Enroll Cert Using File.




| Feature                  | Description                                                           | Options |
|--------------------------|-----------------------------------------------------------------------|---------|
| Enroll Cert Using File   | Enroll Cert Using File.                                               |         |
| Cert GUID                | Input digit character in 11111111-2222-3333-4444-1234567890ab format. |         |
| Commit Changes and Exit  | Commit Changes and Exit                                               |         |
| Discard Changes and Exit | Discard Changes and Exit                                              |         |

### 4.3.15 Intel (R) Ethernet Controller I226-IT – 00:90:FB:84:BE:82



| Feature                       | Description                                        | Options |
|-------------------------------|----------------------------------------------------|---------|
| Link auto-negotiation Timeout | How long the UEFI PXE driver should wait for link. | ★8      |

## 4.4 Security



| Feature                | Description                                                                                                 | Options          |
|------------------------|-------------------------------------------------------------------------------------------------------------|------------------|
| Password Check Mode    | [Setup] check password when enter setup screen.<br>[Power on] check password on every time system power on. | ★Setup, Power On |
| Administrator Password | Set Administrator Password                                                                                  |                  |
| Secure Boot            | Secure Boot configuration                                                                                   |                  |

## Secure Boot

### Secure Boot configuration



| Feature              | Description                                                                                                                                                      | Options            |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|
| Secure Boot          | Secure Boot feature is Active if Secure Boot is Enabled, Platform Key (PK) is enrolled, and the System is in User mode. The mode change requires platform reset. | ★Disabled, Enabled |
| Secure Boot Mode     | Standard or Custom. In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication                      | ★Custom, Standard  |
| Restore Factory keys | Force System to User Mode. Install factory default Secure Boot key databases                                                                                     | Yes, No            |
| Key Management       | Enables expert users to modify Secure Boot Policy variables without variable authentication                                                                      |                    |

## Key Management


Enables expert users to modify Secure Boot Policy variables without variable authentication



| Feature                | Description                                                                                                                      | Options            |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------|--------------------|
| Factory keys Provision | Install factory default Secure Boot key after the platform reset and while the System is in Setup mode.                          | ★Disabled, Enabled |
| Restore Factory keys   | Force System to User Mode. Install factory default Secure Boot key databases                                                     | Yes, No            |
| Enroll Efi Image       | Allow Efi image to run in Secure Boot mode. Enroll SHA256 Hash certificate of a PE image into Authorized Signature Database (db) |                    |

| Feature                       | Description                                                                                                                                                                                                                                                                                                    | Options |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| Platform Key(PK)              | Enroll Factory Defaults or load<br>certificates from a file:<br>1. Public Key Certificate:<br>a) EFI_SIGNATURE_LIST<br>b) EFI_CERT_X509 (DER)<br>c) EFI_CERT_RSA2048 (bin)<br>d) EFI_CERT_SHAXXX<br>2. Authenticated UEFI Variable<br>3. EFI PE/COFF Image (SHA256)<br>Key Source:<br>Factory, Modified, Mixed |         |
| Key Exchange<br>Keys(KEK)     |                                                                                                                                                                                                                                                                                                                |         |
| Authorized<br>Signatures(db)  |                                                                                                                                                                                                                                                                                                                |         |
| Forbidden<br>Signatures(dbx)  |                                                                                                                                                                                                                                                                                                                |         |
| Authorized<br>TimeStamps(dbt) |                                                                                                                                                                                                                                                                                                                |         |
| OsRecovery<br>Signatures(dbr) |                                                                                                                                                                                                                                                                                                                |         |


## 4.5 Boot



| Feature                          | Description                                                                                 | Options                                                                     |
|----------------------------------|---------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| Setup Prompt Timeout             | Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting. | ★1                                                                          |
| Bootup NumLock State             | Select the keyboard NumLock state.                                                          | ★On, Off                                                                    |
| Full Screen LOGO                 | Enables or disables Quiet Boot option and Full screen Logo.                                 | ★Disabled, Enabled                                                          |
| Boot Option #1 ~ #4              | Sets the system boot order                                                                  | Hard Disk, USB Device, Network, UEFI AP: UEFI: Built-in EFI Shell, Disabled |
| UEFI USB Drive BBS Priorities    | Specifies the Boot Device Priority sequence from available UEFI USB Drivers                 |                                                                             |
| UEFI Application Boot Priorities | Specifies the Boot Device Priority sequence from available UEFI Application                 |                                                                             |

**UEFI USB Drive BBS Priorities**


Specifies the Boot Device Priority sequence from available UEFI USB Drivers.



| Feature        | Description                 | Options |
|----------------|-----------------------------|---------|
| Boot Option #1 | Sets the system boot order. |         |


**UEFI Application Boot Priorities**

Specifies the Boot Device Priority sequence from available UEFI Application.



| Feature        | Description                 | Options |
|----------------|-----------------------------|---------|
| Boot Option #1 | Sets the system boot order. |         |

## 4.6 Save& Exit




| Feature                                 | Description                                                                                        | Options |
|-----------------------------------------|----------------------------------------------------------------------------------------------------|---------|
| Save Changes and Reset                  | Reset the system after saving the changes.                                                         |         |
| Discard Changes and Reset               | Reset system setup without saving any changes.                                                     |         |
| Restore Defaults                        | Restore/Load Default values all the setup options.                                                 |         |
| UEFI: Built-in EFI Shell                |                                                                                                    |         |
| Launch EFI Shell from filesystem device | Attempts to Launch EFI Shell application (Shell.efi) from one of the available filesystem devices. |         |

## **LYNX-812C BIOS /EC UEFI Update SOP process under UEFI Shell** Step

1. Prepare a USB DOK.

Step 2. Unzip BIOS update file to the USB DOK.

Step 3. Plug the USB DOK into the target system and then boot in UEFI Shell by selecting UEFI: Built-in EFI Shell in the BIOS Save & Exit page.



Step 4. Under the UEFI shell, direct to your USB DOK, below picture is an example using fs0. Then direct to the folder with BIOS updated file and then enter command: "Update.efi" to start updating BIOS or EC.

```
UEFI Interactive Shell v2.2
EDK II
UEFI v2.80 (American Megatrends, 0x0005001A)
Mapping table
  FS0: Alias(s):HD0b0c0b::BLK1:
        PciRoot(0x0)/Pci(0x14,0x0)/USB(0x1,0x0)/USB(0x2,0x0)/HD(1,MBR,
  BLK0: Alias(s):
        PciRoot(0x0)/Pci(0x14,0x0)/USB(0x1,0x0)/USB(0x2,0x0)
  BLK2: Alias(s):
        PciRoot(0x0)/Pci(0x1A,0x0)/eMMC(0x0)
Press ESC in 5 seconds to skip startup.nsh or any other key to continue.
Shell> fs0:
FS0:\> cd Update_LSMC-M1013_0_0_11
FS0:\Update_LSMC-M1013_0_0_11> ls
Directory of: FS0:\Update_LSMC-M1013_0_0_11\
09/19/2025  15:31 <DIR>          8,192  ..
09/19/2025  15:31 <DIR>           0      ...
09/03/2025  12:31                374    ReadMe.txt
09/03/2025  12:31          7,044,369    Update.efi
                2 File(s)      7,044,743 bytes
                2 Dir(s)
FS0:\Update_LSMC-M1013_0_0_11> Update.efi_
```


(BIOS File Update)

```
UEFI Interactive Shell v2.2
EDK II
UEFI v2.80 (American Megatrends, 0x0005001A)
Mapping table
  FS0: Alias(s):HD0b0c0b::BLK1:
        PciRoot(0x0)/Pci(0x14,0x0)/USB(0x1,0x0)/USB(0x2,0x0)/HD(1,MBR,0
  BLK0: Alias(s):
        PciRoot(0x0)/Pci(0x14,0x0)/USB(0x1,0x0)/USB(0x2,0x0)
  BLK2: Alias(s):
        PciRoot(0x0)/Pci(0x1A,0x0)/eMMC(0x0)
Press ESC in 5 seconds to skip startup.nsh or any other key to continue.
Shell> fs0:
FS0:\> cd EC_LSMC-M1013_0_5
FS0:\EC_LSMC-M1013_0_5> ls
Directory of: FS0:\EC_LSMC-M1013_0_5\
09/19/2025  16:01 <DIR>          8,192  ..
09/19/2025  16:01 <DIR>           0      ...
07/01/2025  14:31                377    ReadMe.txt
07/01/2025  14:31          72,961    Update.efi
                2 File(s)      73,338 bytes
                2 Dir(s)
FS0:\EC_LSMC-M1013_0_5> Update.efi_
```

(EC File Update)

Step 5. The updating process will start, and you can see the updating progress. When you see the following pictures, which means the BIOS update processes finished.

Please cut the AC power off and wait for 10 seconds before powering on.



```
UEFI Interactive Shell v2.2
EDK II
UEFI v2.80 (American Megatrends, 0x0005001A)
Mapping table
  FS0: Alias(s):HD0b0c0b::BLK1:
        PciRoot(0x0)/Pci(0x14,0x0)/USB(0x1,0x0)/USB(0x2,0x0)/HD(1,MBR,0x00E
  BLK0: Alias(s):
        PciRoot(0x0)/Pci(0x14,0x0)/USB(0x1,0x0)/USB(0x2,0x0)
  BLK2: Alias(s):
        PciRoot(0x0)/Pci(0x1A,0x0)/eMMC(0x0)
Intel (R) Flash Programming Tool Version: 16.50.0.1215
Copyright (C) 2005 - 2022, Intel Corporation. All rights reserved.

Reading HSFSTS register... Flash Descriptor: Valid

--- Flash Devices Found ---
ID:0xC22019    Size: 32768KB (262144Kb)

GbE Region does not exist.

- Erasing Flash Block [0x20000000] - 100 percent complete.
- Programming Flash [0x20000000] 32768KB of 32768KB - 100 percent complete.
- Verifying Flash [0x20000000] 32772KB of 32768KB - 100 percent complete.
RESULT: The data is identical.

FPT Operation Successful.

FS0:\Update_LSMC-M1013_0_0_11\> _
```

(BIOS update finished)

```

UEFI Interactive Shell v2.2
EDK II
UEFI v2.80 (American Megatrends, 0x0005001A)
Mapping table
  FS0: Alias(s):HD0b0c0b:;BLK1:
        PciRoot(0x0)/Pci(0x14,0x0)/USB(0x1,0x0)/USB(0x2,0x0)/HD(1,MBR,
  BLK0: Alias(s):
        PciRoot(0x0)/Pci(0x14,0x0)/USB(0x1,0x0)/USB(0x2,0x0)
  BLK2: Alias(s):
        PciRoot(0x0)/Pci(0x1A,0x0)/eMMC(0x0)
Current shell version is v2.x
ITE EC Flash Utility for UEFI Shell, Version : 1.4.0 (64)
<Re-Write by FoxYang .. 2021/12/22 >

[/NOKBC] support
!!Please don't use KB/MS during updating ...!!
Device ID       : EF 40 14 0
SPI Vendor      : Winbond
Eraseing...     : ██████████ -- Erase OK.
Erase Verify... : ██████████ -- Erase Verify OK.
Programing...   : ██████████ -- Programing OK.
Verify...       : ██████████ -- Verify OK.

Please turn off power(G3) by manual , let EC reload new image !!
FS0:\EC_LSMC-M1013_0_5\>

```

(EC update finished)

# Chapter 5

## IMPORTANT INSTRUCTION

- 5.1 Note on the Warranty
- 5.2 Exclusion of Accident Liability Obligation
- 5.3 Liability Limitations / Exemption from the Warranty Obligation
- 5.4 Declaration of Conformity

## 5.1 Note on the Warranty

Due to their limited-service life, parts which, by their nature, are especially subject to wear are not included in the guarantee beyond the legal stipulations.

## 5.2 Exclusion of Accident Liability

### Obligation

Portwell, Inc. shall be exempt from the statutory accident liability obligation if users fail to abide by the safety instructions.

## 5.3 Liability Limitations/Exemption from the Warranty Obligation

In the event of damage to the system unit caused by failure to abide by the hints in this manual and on the unit (especially the safety instructions), Portwell, Inc. shall not be required to respect the warranty even during the warranty period and shall be free from the statutory accident liability obligation.

## 5.4 Declaration of Conformity

### EMC

CE/FCC Class A

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.

2. This equipment must accept any interference that may cause undesired operation

# Chapter 6

## Portwell Software Service

### 6.1 PET tool

## 6.1 PET Tool

### **Portwell Evaluation Tool (PET)**

The Portwell Evaluation Tool (PET) is an API which Portwell's customers can access the GPIO, I2C, SMBus, etc under Windows and Linux OS. For more information, please contact Portwell.

Please visit our Download Center to obtain the necessary documents and files, such as the catalog, user manual, PET, BIOS, and driver.

附網址

If you have other additional technical information or requests which are not covered in this manual, please fill in the technical request form as below hyperlink

We will do our best to provide a suggestion or solution for you.





Please verify specifications before quoting. This guide is intended for reference purposes only. All product specifications are subject to change without notice. No part of this publication may be reproduced in any form or by any means, such as electronically, by photocopying, recording, or otherwise, without prior written permission from the publisher. All brand and product names are trademarks or registered trademarks of their respective companies.



#### Portwell, Inc. Headquarters

No. 242, Bo'AI St., Shu-Lin Dist,  
New Taipei City 238, Taiwan  
Tel: +886-2-7731-8888  
Fax: +886-2-7731-9888  
E-mail: [info@portwell.com.tw](mailto:info@portwell.com.tw)  
[www.portwell.com.tw](http://www.portwell.com.tw)

#### American Portwell

(Fremont, CA)  
Tel: +1-510-403-3399  
E-mail: [info@portwell.com](mailto:info@portwell.com)  
[www.portwell.com](http://www.portwell.com)

#### Portwell UK Ltd.

Tel: +44(0)1235-750-760  
E-mail: [info@portwell.eu](mailto:info@portwell.eu)  
[www.portwell.eu](http://www.portwell.eu)

#### Portwell Japan, Inc.

(Tokyo)  
Tel: +81-3-6902-9225  
E-mail: [info@portwell.co.jp](mailto:info@portwell.co.jp)  
[www.portwell.co.jp](http://www.portwell.co.jp)

#### Portwell Japan, Inc.

(Osaka)  
Tel: +81-6-4807-7721  
E-mail: [info@portwell.co.jp](mailto:info@portwell.co.jp)  
[www.portwell.co.jp](http://www.portwell.co.jp)

#### European Portwell

Tel: +31-252-620790  
E-mail: [info@portwell.eu](mailto:info@portwell.eu)  
[www.portwell.eu](http://www.portwell.eu)

#### KIOSK Embedded Systems GmbH

Tel: +49-8152-3962-500  
E-mail: [info@portwell.eu](mailto:info@portwell.eu)  
[www.portwell.de](http://www.portwell.de)

#### Shanghai Portwell

Tel: +86-21-5771-2505  
E-mail: [info@portwell.com.cn](mailto:info@portwell.com.cn)  
[www.portwell.com.cn](http://www.portwell.com.cn)

#### Portwell Korea, Inc.

Tel: +82-31-450-3043  
E-mail: [info@portwell.co.kr](mailto:info@portwell.co.kr)  
[www.portwell.co.kr](http://www.portwell.co.kr)

#### Portwell India Technology Private Limited

Tel: +91-80-4168-4255  
E-mail: [enquiry@portwell.in](mailto:enquiry@portwell.in)  
[www.portwell.in](http://www.portwell.in)